

CODE

CH-323 V19.3

TV

A.R.SYSTEM 2001,2002,5053,5054.
ACCENT 5066.
ACE 2198.
ACER 1484.
ACME 0013.
ACOUSTIC SOLUTIONS 6003,6013.
ADA 0008.
ADC 0008,0012.
ADMIRAL 2025,2104,2227,5085,5101,5103,5171.
ADYSON 0001,0002,0019,0047,0108.
AEG 6003.
AGASHI 0003,2004,2208.
AGAZ 2025,2208.
AGB 0002.
AGFAPHOTO 6020.
AIKO 0003,0004,0009,0123,2031,2195,2208,5055.
AIOSTAY 2008,2017,2025,5094.
AIWA 0184,0248,0291,5150,5163,6024.
AK 2004,2005,5055.
AKAI 0004,0006,0008,0009,0011,0051,0061,0068,0069,0086,0088,0133,0141,0169,0200,1410,2004,2005,2009,2017,2020,2025,2031,2071,2108,2114,2195,2208,2209,2220,2226,5012,5055,5060,5067,5071,5079,5083,5093,5094,5095,5102,5153,6001,6013,6021,6024,6033.
AKIBA 0011,2031,2055,2108,2115,2209,2216,2217,5066,5093.
AKURA 0002,0009,0011,0071,0074,0169,6000,6003,6004,6005,6007,6015,6020.
ALARON 2208.
ALBA 0003,0009,0011,0027,0028,0047,0062,0068,0083,0162,0169,0245,0248,2017,2031,2114,2208,2209,2216,2219,5094,5098,6003,6013,6019,6021.
ALBIRAL 0037,2000,2001,2017,2095,2108,5049,5053,5054,5066,5077,5094.
ALHORI 2004,5055.
ALKOS 0164.
ALLOGRAN 0157,2004,2014,2053,5055,5086,5089,5140.
ALLSTAR 0051.
ALTUS 0042.
AM 5054,5060,5067.
AMPLVISION 0003,5054,5055.
AMSTRAD 0002,0009,0011,0013,0030,0068,0069,0071,0074,0108,0123,2025,2031,2108,2209,2217,2227,5066,5067.
AMTECH 6011.
ANAM 0009,0065,0109.
ANGLO 0009,2108,5066.
ANITECH 0002,0009,0043,0109,2004,2021,2025,2029,2108,2110,5077.
ANSONIC 0009,0014,2025,2094,2108,2115,6003.
ANTECNO 2031.
AOC 0134,6019.
ARC EN CIEL 0045,0126,0139.
ARCAM 0003.
ARCELIK 5070,5094,5099,5175,5176,5177,5178,5185.
ARCTIC 6001.
ARISTONA 0051,0169.
ART MITO 6003.
ARTHUR MARTIN 0158.
ART-TECH 2110.
ASA 0000,0016,0017,0018,0021,0110,2006,2008,2012,2063,2071,2104,2109,2148,5032,5040,5041,5043,5085,5095.

TV

1

ASBERG 0043,0051,2021,2114,5079.
ASORA 2025.
ASTON 5119.
ASTRA 0009,2025,5054,5094,5120,5159.
ASTRO 2001,2017.
ASTRO SOUND 5054,5077,5094.
ASUKA 0002,0003,0011,2017,2029,2031,2209,5094.
ATLANTIC 0003,0051,0157,0169,2208,5029,6033.
ATORI 0009.
ATORO 2025.
AUCHAN 2005,6033.
AUDIOSONIC 0003,0009,0011,0051,0090,0139,0157,0169,2108,2209,5049,5053,5055,5066,5077,5087,6015.
AUDIOSTAR 2025,2031.
AUDIOTON 0003,2004,2025,2029,5055.
AURORA 2004,2148,5055,5060.
AUSIND 0043,2007,2035,5035.
AUTOVON 6003.
AUTOVOX 0000,0002,0003,0043,0101,0125,0157,2004,2006,2011,2013,2014,2053,2054,2070,2100,2102,5039,5050,5055,5060,5086,5089,5125,5139,5152.
AWA 2023,2025,2108,2147,2194,2208,2217,5055,5060.
AXION 2025.
AYA 6033.
AZUKI 6020.
BAIER 6020.
BAIHUA 2031.
BAIRD 0111,0139,0245,2215,6029.
BANG & OLTYSÉN 2104.
BANG & OLTYSÓN 0000,0199.
BARCO 0112,5047,5094.
BARCOM 2069,2104.
BASIC LINE 0009,0011,0051,0245,2005,2031,2110,2209,5086,5089,5090.
BASTIDE 0003.
BAUR 0076,0118,0132,0141,0169,2005,2009,2014,2023,2025,2037,2041,2082,2232,2245,5031,5086,5088,5089,5102,5167.
BAZIN 2004,5045,5055,5087.
BBK 6000.
BEKO 0007,0034,0042,0083,0095,1064,2091,2115,2152,2201,2233,5070,5087,5094,5099,5100,5175,5176,5177,5178,5185,6001.
BEKOTEKNIK 2115.
BELSON 6003.
BENQ 6019.
BEON 0051,0169,5079.
BEST 0113.
BESTAR 0051,0245,2115.
BIC 0011,2209.
BIFONIC 2004,2025,5055.
BIG STONE 2025,2108,5060,5066.
BINATONE 0003.
BLACK DIAMOND 0171.
BLACK PANTHER 0245.
BLACK STAR 0129.
BLAUPUNKT 0008,0022,0100,0117,0135,0202,2009,2016,2157,2158,2159,2160,2161,2162,2167,2224,5031,5034,5053,5062,5116,6005,6029.
BLAUSONIC 2004,5055.
BLOOM 0015.
BLU:SENS 6011.
BLUE SKY 6001,6005.
BLUESKY 0011,1485,2201,2209,2216,2219.
BLUESTAR 2005,2017,2110,5094.
BLUSH 6005.
BOCA 6001.
BOGO 6024.
BONDSTEC 0129,2100.
BOOTS 0003.
BOSCH BAUER 2029,2158,2162.

TV

2

BOSTON 2104.
 BOTECH 5018,5021.
 BPL 2108,2110,2112.
 BRANDT 0022,0036,0045,0126,0127,0139,2000,2001,2004,2017,2029,2035,2037,2049,2052,2067,2069,2076,2151,2211,2213,2219,2221,2235,2236,2244,5212,6003.
 BRIGMTON 2001,2004.
 BRIMAX 6005.
 BRION VEGA 0000,0051,0169,2070,2104,2111,2112,2127,2129,2130,2181,2227,5043,5051,5052,5125,5130,5165.
 BRISTOL 2104.
 BRITANNIA 0003,2004,2208,5055,5092.
 BROKSONIC 0920,2025.
 BROTHER 2108,5066,5120.
 BRUNS 0000,0007,2107,5077.
 BSR 0131,2015,2017,2018,5087,5140.
 BUSH 0009,0011,0019,0024,0027,0028,0032,0039,0051,0068,0107,0115,0131,0132,0139,0167,0169,0205,0245,0248,2110,5098,6000,6001,6003,6004,6013,6015,6019,6020,6032,6033.
 BUSH(ATAK) 5088,5093,5094.
 BUSH(UK) 2017,2019,2020,2037,2064,2209,2216,2219.
 CABLETIME 2171,2172,2176.
 CAMPER 5087.
 CANTON 2031.
 CAPSONIC 0002,2108,5066.
 CARREFOUR 0027.
 CARTEL 5007,5014,5120.
 CASCADE 0009.
 CATHAY 0051,0169.
 CBM 2021.
 CELLO 6007.
 CELNT 2068.
 CENTRUM 0168,0205.
 CENTURION 0051,0169.
 CENTURY 0000,2094,2095,2104,5049.
 CERCUS 6003,6033.
 CGE 0043,0047,0129,0131,2017,2020,2021,2025,2094,2100,2114,2115,2157,2161,2224,5049,5079,5087,5093,5094,5103.
 CGM 2025,2031,2062,2103,2108,2110,2115,5066.
 CHANGHONG 2246,2290,2302,2303,2305,2306,2307,2310,2311.
 CHAPARRAL 2144.
 CHL 6021.
 CIATE 2104.
 CIE 2025,2031,5060,5140.
 CIHAN 5087,5094.
 CIMLINE 0009,0028,2209.
 CITY 0009.
 CLARIVOX 0037,0169,2000,2001,2008,2017,2035,2104,2108,2113,5035,5049,5053,5054,5082.
 CLATRONIC 0002,0003,0009,0011,0030,0043,0051,0083,0129,2004,2017,2021,2025,2029,2031,2094,2095,2108,2110,2114,2115,2209.
 CLAYTON 2017.
 CMX 6021.
 COFADEL 5070,5076.
 COLORLUX 2104.
 COLORMATT 2104.
 COLORTRON 2104,5067,5095,5132.
 COMBITECH 0248.
 CONCEPT 5083.
 CONCORDE 0009,2025.
 CONDOR 0003,0051,0083,0198,0245,2021,2025,2029,2108,2114,2115,2127,2208,5066,5077,5079.
 CONIA 6000,6004,6023.
 CONRAC 0038,1395.
 CONTEC 0003,0009,0027,0029,0030,2004,2015,2025,2034,2208,5055,5066,5140.
 CONTIN.EDISON 5044,5048,5063,5070,5071,5076.
 CONTIN.FR 5132.
 CONTINENTAL 0022,0036,0045,0111,0126,2211,2219.
 CONTINENTAL EDISON 6024,6033.

TV

COSMEL 0009,2025.
 CPREMIER 5024.
 CPRTEC .
 CROSLEY 0000,0043,0129,0131,2021,2022,2094,2104,2157,2224,5033,5049,5096.
 CROWN 0009,0043,0047,0051,0083,0121,0169,0245,2017,2021,2025,2031,2091,2114,2115,2219,6001.
 CROWNONWAS AKY 5033,5066,5067,5079.
 CS ELECTRONICS 0003,0011,0129,2004,2031,2100,2208,2209.
 CTC 0129.
 CTC CLATRONIC 0014,5049,5055,5066,5077,5079.
 CYBERCOM 0002,0009,0038,0042,0044,0047,0061,0063,0067,0068,0103,0107,0115,0127,0154,0168,0169,0171,0177,0185,0205,0206,0207,0208,0209,0210,0228,0248,0291,0343,0924,0933.
 CYBERMAXX 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0087,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005.
 CYBERPIX 6003.
 CYBERTRON 0011,2209.
 CYMATIC 2000,2004,2017,5053,5055,5087,5094.
 CYTRON 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0087,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005.
 DAEWOO 0003,0009,0051,0094,0115,0191,0245,2004,2025,2031,2117,2138,2208,2209,2248,5049,5050,5055,5060,5083,5117,5157,6011.
 DAINICHI 0011,2004,2208,2209.
 DANSAI 0002,0051,0169,2108,2195,2208,5066.
 DANSETTE 2217.
 DANTAX 0034,0088,0113,0161,0169,0171,6001.
 DATSURA 0121.
 DAYTON 0009.
 DAYTRON 0245.
 DCE 0042,0205.
 DE GRAAF 0006,0019,0033,2037,5088.
 DECCA 0003,0004,0030,0051,0123,0169,5053,5055,8505.
 DECCA(UK) 2002,2004.
 DECCACOLOR 0015.
 DELL 0025.
 DEMACOLOR 2021.
 DENVER 2025,6005,6007,6011,6020,6021.
 DESMET 0051,0169,2002,2005,2017,2025,2029,2104,5053,5094.
 DEW 6007.
 DGM 6020.
 DIAMOND 5060.
 DIGIHOME 6003,6033.
 DIGITATE 6020.
 DIGITEK 6005.
 DIGITOR 0227,0228.
 DIGITREX 6021.
 DINASTY 2025.
 DISNEY 0148.
 DMTECH 6011,6017.
 DOMEOS 5155.
 DORIC 5035,5096.
 DSE DIGITOR 2023,2025.
 DTS 0009.
 DUAL 0002,0003,0009,0038,0042,0044,0047,0061,0063,0067,0068,0089,0103,0107,0115,0125,0126,0127,0131,0139,0154,0160,0168,0169,0171,0177,0206,0207,0208,0210,0228,0248,0291,0343,0924,0933,2004,2005,2010,2014,2017,2020,2025,2041,2179,2215,2227,2232,5030,5032,5049,5055,5086,5089,5093,5094,5111,6003.
 DUAL-TEC 0003,0009,0131,2004,2010,2017,5030,5032,5049,5055,5086,5089,5093,5094,5155,5167.
 DUMONT 0000,0003,0014,0017,0018,2008,2012,2021,2104,2114,2148,2238,5032,5040,5041,5077,5079,5096.

TV

DUNAI 2017.
DURABRAND 0228,0933,1006,1007,1008,1009,1088,6001.
DUX 0169.
D-VISION 6020.
DXI 0009,0051,0169,2025,2105.
DYNATRON 0051,0169.
DYNISTY 5060.
DYON 6024.
EASY LIVING 6005,6018.
ECG 6020,6021.
EDISON 0139,5212.
ELAN 2004.
ELBE 0037,0108,0157,2000,2001,2004,2017,2034,2116,2127,2209,2227,5053,5054,5055,5094,5096,5101,5103,5144.
ELCIT 0000.
ELECTRO TECH 0009.
ELECTRONIC 6001.
ELEKTA 2025,2108,2110.
ELEKTRON 2017.
ELEKTRONICA 2004.
ELEKTRONSKA 2000,2017,5053,5094.
ELEKTRONTECH 2025.
ELITE 0011,0051,2029,2031,2209,2224,5171.
ELMAN 0014,0131,2000,2005,2017,2238,5077,5094.
ELN 0003,0016,0018,0051,0169,2005,2010,2012,2025,2037,2148,2208,2220,5032,5055,5095.
ELTA 0009,2017,2025,2064,2108,2110,2208.
ELTAX 2108.
EMERSON 0000,0127,0141,2004,2008,2017,2021,2029,2035,2095,2104,2108,2115,2117,5040,5049,5055,5066,5077,5094.
E-MOTION 6005,6029.
ENGEL 2017,5094,6024.
ERAE 1003.
ERRES 0051,0169.
ESC 0245.
ETRON 0009,2005,2025,5067,5133.
EUROCOM 2017,5094.
EURO-FEEL 0002,2004.
EUROLINE 0088,0149,0169.
EUROMAN 0002,0003,0051,2004,2208,5033,5055.
EUROPHON 0003,0014,0051,0123,0131,2000,2004,2017,2024,2095,2238,5049,5053,5055,5077,5081,5094.
EUROSTAR 2148.
EVERLINE 6024.
EVESHAM 6003.
EXPERT 0157,2005,5029,5086.
FAGOR 2017,5094,5118.
FAIRTEC 0204,1416,1485.
FENNER 0009,0115,2025,2110,2166,5060,6003.
FERGUSON 0035,0036,0037,0050,0052,0111,0127,0163,0166,0169,2001,2002,2004,2005,2009,2012,2017,2019,2025,2033,2034,2035,2041,2052,2079,2082,2086,2087,2088,2089,2090,2091,2093,2097,2101,2108,2124,2148,2155,2180,2211,2213,2221,2227,2237,2241,5055,5057,5065,5066,5068,5070,5071,5092,5096,5102,5104,5110,5111,5124,5131,5135,6013,6021.
FIDELIS 2004,2025,5055.
FIDELITY 0003,0019,0068,0074,0096.
FIDELITY(UK) 2003,2004,2014,2025,2026,2155,2208.
FILMNET 2131,2173.
FILSAI 2004,2025,5055.
FINLANDIA 0006,0019,0110,0128,2017,2037,2220,5087,5088.
FINLUX 0000,0003,0004,0014,0016,0017,0018,0042,0043,0051,0061,0063,0087,0110,0123,0131,0157,0167,0169,2002,2004,2006,2007,2008,2012,2017,2021,2022,2027,2035,2063,2068,2071,2100,2109,2114,2127,2148,2226,2238,5032,5035,5040,5041,5050,5053,5077,5079,5095,5096,5131,5153,6003,6033.
FIRSTLINE 0003,0026,0051,0062,0129,2001,2004,2005,2014,2017,2020,2025,2029,2094,2208,2216,5035,5049,5054,5055,5060,5086,5089,5090,5093,5094.

FISHER 0000,0003,0006,0018,0027,0029,0040,0083,0131,2004,2012,2014,2022,2028,2034,2079,2104,2113,2115,2179,2232,5032,5055,5056,5057,5086,5089,5096,5102,5167.
FLDELITY 5048,5049,5055,5065,5067,5086,5089,5092,5094.
FLINT 0051,0113,2209,5083.
FOEHN & HIRSCH 6010.
FORMENT 0000,0001,0003,0043,0125,0131,0133,0169,5035,5053,5055,5066,5077,5079,5087,5094,5096.
FORMENTIPHOE NIX 2000,2003,2004,2005,2007,2017,2021,2022,2025,2029,2030,2035,2104,2108,2208,2224,2238.
FORTRESS 0000,0001,2104.
FRANCETELECOM 2186.
FRONTECH 0002,0009,0019,0021,0068,0118,0120,0129,2004,2025,2064,2094,2100,2100,2117,2229,5049,5050,5055,5088,5094.
FUJICOM 6005,6024.
FUJITSU 0002,0004,0116,0157,2004,2010,2031,2053,2110,5022,5030,5041,5055,5077,5139,5140,5152.
FUNAI 2015,2025,2108,2217,2234,5066,5140,6001.
GALACTEX 5055,5066.
GALAXIS 2008,2021,2094,2114,2115,5079.
GALAXY 0047,0083,5055,5077,5079.
GALERIA 2025.
GBC 0009,0027,0131,2000,2002,2004,2017,2022,2025,2031,2032,2033,2034,2110,2117,2209,5049,5060,5067,5085,5094,5096.
GE 2213.
GEANT CASINO 2005.
GEBER 2005,5086,5089,5090.
GEC 0003,0004,0041,0051,0123,0132,0141,0169,5053,5055,5086,5087,5088,5096,5141.
GEC(UK) 2002,2004,2005,2021,2033,2055.
GELESO 5049,5053,5060,5085,5094,5096.
GELOSO 0009,0019,0131,2000,2004,2017,2022,2025,2031,2098,2099.
GENERAL 2211,2218.
GENERAL CORPORATION 2004,2034,2053.
GENERAL STAR 5115.
GENERAL TECHINC 2025.
GENERAL TECHNIC 0009,0248.
GENEXXA 0011,0021,0051,2209,2217.
GERICOM 0049,1022,1023,1064.
GIANT 5055,5073.
GITEM 5031,5070,5090,5091.
GM 5066.
GMG 2025,2108,2114,5066,5079.
GOGEN 6003,6033.
GOLD 6007.
GOLDHAND 2004,2025,2208.
GOLDSTAR 0003,0009,0012,0019,0051,0084,0129,0131,0169,0171,0261,2003,2004,2010,2017,2025,2064,2094,2100,2102,2108,2117,2177,2189,2190,2208,2227,2229,5030,5037,5050,5055,5078,5080,5088,5094,5115,5155.
GOODING 5132.
GOODMANS 0002,0004,0009,0027,0028,0051,0068,0111,0115,0127,0169,0171,0245,0283,2004,2017,2025,2031,2034,2078,2195,2213,2215,2219,5037,5055,5060,5067,5094,6000,6003,6004,6005,6015,6018,6019.
GORENJE 0083,2031,2115,2118,5033,5086,5089,6003.
GP 2004.
GPM 0011,2025,2031,2108,2209.
GRAETZ 0021,0141,0142,6003.
GRAETZ(ITD) 5154.
GRANADA 0003,0004,0006,0019,0027,0031,0040,0043,0051,0054,0064,0123,0127,0128,0133,0138,0169,5035,5053,5055,5073,5087,5088,5092,5096,5104,5112,5143.
GRANADA(UK) 2002,2004,2005,2023,2034,2035,2036,2037,2038,2055,2071,2213,2237.
GRANDIN 0009,0011,0120,0169,0245,2005,2017,2029,2031,2055,2110,2201,2209,5086,

5094,5096,6001,6003,6033.
 GREAT WALL 2178,5066,5083.
 GRENADIER 5094,5115.
 GRONIC 2004,2017,5055,5077,5094.
 GRUNDIG 0008,0017,0043,0091,0101,0114,0117,
 0135,0136,2003,2007,2009,2011,2016,
 2035,2039,2040,2042,2063,2063,2219,
 5031,5035,5038,5132,5142,5166,6000,
 6003,6004,6020,6021.
 GTT 2025,2114,5079.
 H&B 0228,0343,6017.
 HAAZ 0228.
 HAIER 6019,6032.
 HALIFAX 0002,0003,2208.
 HAMERSTEIN 5055,5059,5066,5068.
 HAMPTON 0003,2004,2208,5055,5096.
 HANNSPREE 6019.
 HANSEATH 6017.
 HANSEATIC 0003,0007,0009,0026,0027,0051,0083,
 0118,0131,0141,0169,2000,2004,2005,
 2014,2017,2022,2023,2025,2029,2031,
 2034,2041,2064,5031,5053,5055,5086,
 5088,5089,5096,5140.
 HANSOL 1019.
 HANTAREX 0009,0123,2000,2025,5053.
 HAPO 2031.
 HAPPY 2031.
 HARWOOD 0171,2217.
 HB 0015,0042,0095,0168,1003,1011,1020,
 1389.
 HCM 0002,0003,0009,0074,2004,2017,2025,
 2108,2110,2209,2217,5055,5094.
 HEMMERMANN 2004,2014,5055,5075,5077,5086,5089.
 HEXA 2017,5082,5094.
 HIFIVOX 0139.
 HIGASHI 2004,2005,2025,2031,2034,2108,5055.
 HIKONA 2209,6015.
 HILINE 5066,5067.
 HINARI 0006,0009,0011,0027,0043,0051,0137,
 0169,0171,0248,2025,2034,2043,2044,
 2209,2219.
 HISAWA 0011,0113,2017,2031,2110,2209.
 HISENSE 0204,1415,1416,1417,1485,1486,5088.
 HISONIX 2025.
 HITACHI 0003,0004,0016,0019,0021,0023,0027,
 0033,0041,0045,0047,0085,0118,0123,
 0131,0133,0134,0138,0139,0140,0141,
 0142,0144,0153,0213,1013,2004,2009,
 2032,2033,2034,2037,2045,2047,2055,
 2071,2117,2148,2149,2196,2215,2235,
 2236,2254,5055,5071,5078,5086,5087,
 5088,5089,5094,5095,5096,5099,5100,
 5124,5127,5141,5212,6003,6004,6008,
 6016,6018,6019,6033.
 HITSU 2031,2208.
 HKC 6024.
 HORNYPHON 0051.
 HORYZONT 2017.
 HOSHAI 0011,2031,2110,2209.
 HOTEL TV 2193,5186.
 HUANYU 0003,0115,2208.
 HUNTER 5147.
 HYGASHI 0003,2208.
 HYPER 0003,0009,0129,0131,2003,2004,2017,
 2025,2031,2100,2102,2108,2208,5050,
 5055,5061,5067,5087,5094,5124.
 HYPSON 0002,0003,0051,0169,2001,2004,2017,
 2025,2108,2110,2229,5066.
 HYUNDAI 1010,2314,2315,2316,5026,5136,6003,
 6007.
 IBERVISAO 2005,2017,5086,5089,5094.
 ICE 0002,0003,0009,0011,0051,0068,2004,
 2025,2031,2094,2108,2208,2209,5066,
 5067.
 ICES 2208,2209.
 ICS 2025.
 IEG 2004,5055.
 IİYAMA 1414.
 I-JOY 6021,6024.
 IMPER 5066,5120.
 IMPERIAL 0021,0043,0047,0051,0083,0129,0131,
 2017,2020,2021,2094,2095,2100,2108,
 2114,2115,2117,2157,2161,2224,5049,
 5066,5079,5087,5093,5094,5103.
 INCOBE 2004,2025.

TV

7

INDDISIT 0024,0101,2241,5072.
 INDIANA 0051,0169.
 INF.REM.CONTR 5131.
 INGO DEVICES 6020.
 INNO HIT 6003.
 INNOHIT 0003,0004,0009,0011,0051,0093,0123,
 0169,0245,2000,2004,2017,2020,2021,
 2044,2094,2095,2114,2115,2117,2161,
 2209,2224,2229,5037,5049,5053,5055,
 5067,5096.
 INNOVATION 0002,0009,0061,0067,0068,0103,0107,
 0111,0115,0154,0168,0169,0171,0177,
 0248,0291.
 INOVIA 6032.
 INSAR 6003,6033.
 INT 2108,2229.
 INTER(265) 2204.
 INTERBURG 2025.
 INTERBUY 0009,0109,0129,2229,5050.
 INTERCORD 2232.
 INTERDISCOUNT5070.
 INTERFUNK 0000,0021,0051,0129,0139,0141,0169,
 2005,2023,2032,2035,2036,2037,2041,
 2048,2049,2050,2055,2094,2104,2114,
 2115,2158,2160,2237,5037,5043,5049,
 5053,5055,5062,5067,5070,5079,5086,
 5089,5090,5096.
 INTERTRONIC 0894.
 INTERVISION 0002,0003,0014,0109,2004,2005,2017,
 2095,2108,2115,2117,2209,2219,2238,
 5049,5050,5055,5077,5080,5094.
 ISIS 6033.
 ISKRA 2000,2004,2017,2238,5053,5055,5077,
 5094.
 ISUKAI 0011,2209.
 IT 2203.
 ITC 0003,0131,2004,2017,5055,5094.
 ITL 2025.
 ITS 0011,0051,0068,2004,2025,2031,2108,
 2110,2208,2209.
 ITT 0009,0021,0031,0061,0132,0133,0141,
 0142,0143,6033.
 ITT SCHAUB LOREI 5086,5089,5094,5096,5113,5153.
 ITT/NOKIA 0021,0133,0142,2005,2025,2032,2035,
 2048,2049,2051,2119,2120,2220,5029,
 5032,5040,5060,5079,5084,5086,5087,
 5088,5089,5090,5092,5094,5095,5096,
 5102,5122,5131,5153.
 ITV 0009,0088,0169,0171,0245.
 JANCO 2174,2175.
 JAY-TECH 6020,6021.
 JEC 0164,2195.
 JET POINT 5068.
 JGC 6005.
 JOHNSON 2004,5055.
 JTC 6021.
 JVC 0027,0051,0053,0068,2034,2052,2078,
 2209,5000,5019,5027,5043,5065,5067,
 5068,5134,5135,5158,6009,6018,6033.
 KAIDO 2064.
 KAISUI 0003,0009,0011,0120,2004,2025,2031,
 2108,2110,2114,2208,2209,2229,5055,
 5079,5083,5153.
 KAMBROOK 2004,2108,5055,5066,5071,5080.
 KAMOSONIC 0003,2004,5055.
 KAMP 0003,2208.
 KAPSCH 0021,0157,2005,2012,2053,2055,5029,
 5032,5096.
 KARCHER 0003,0009,0016,0037,0169,2001,2004,
 2025,2064,2110,5041,5054,5055,5081,
 5087,5088.
 KARDON 5139,5152.
 KAUASONIC 5147.
 KAWASHO 2208.
 KAYA 2025.
 KELVINATOR 5078.
 KENDO 0014,0019,0028,0108,0245,2004,2017,
 2025,2095,2127,2227,5030,5049,5055,
 5077,5085,5096,5103,5139,5152.
 KENNEDY 0131,0157,2010,2022,2053,2054,2095,
 2104,2127,2227,5030,5049,5070,5096,
 5103,5139,5152.
 KIC 5055.
 KIMAY 2108,2229.
 KING TV 0015.

TV

8

KINGSLEY 0003,2208.
KIOTA 5066.
KITT 2004,2025,2108,5055,5066.
KLARMAX 2000,2001,2004,2017,5053,5054,5055,5087,5094.
KNEISSEL 0174,2004,2127,5055,5103.
KOENIG 2029,5096.
KOERTING 5086,5089.
KOLIN 2017,2250.
KOLSTER 0051,2001,2004,2017,2031,2095,2108,2117,5049,5050,5054,5055,5077,5094.
KONIG 2023.
KONKA 0011,0047,0068,0229,2031,2209,5011,5013,5146.
KONTAK 2219,5132.
KORPEL 0051,0169.
KORTING 0000,2029,2104,2106,2115.
KOTRON 2108,2217,5066.
KOYODA 0009.
KRAKING 2017.
KRONNE 2004,2017,5055,5094.
KTV 0003.
KUBA ELECTRONIC 2014,2037,2232,5167.
KUNFT 6033.
KUPPERSBUSCH 6003.
KURO 0121.
KYOSHU 2217.
KYOTO 0037,2004,2017,5053,5055,5094.
LAVIS 2000,2001,2005,2012,5053.
LEADER 5162.
LEGEND 5055,5066.
LENCO 0009,0245,2005,2012,2025,2031,2064,2108,2123,2164,2165,2166,2238,5060,5077,6015.
LENOIR 0003,0009,2004,2014,2025,2110,5055,5060,5086,5089.
LESA 0129.
LESENKOTTER 2158.
LEXUS 2108.
LEYCO 0002,0004,0051,0169,2015,2108,2110,5066,5140.
LFE 0002,0009,0061,0067,0068,0103,0107,0111,0115,0154,0168,0169,0171,0177,0205,0291.
LG 0003,0009,0019,0051,0084,0088,0119,0129,0131,0149,0169,0171,0261,2208,5037,5155,6010,6012.
LIESENK 0169.
LIFETEC 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005,2025,2031,2108,2209,2216.
LIFTED 6017.
LINTON 2232.
LLOYDS 5035,5055,5066,5096.
LOEWE 0000,0051,0097,0098,0169,1399,5001,5086.
LOEWE OPTA 2000,2002,2012,2023,2041,2104,2105,2141,2168,5032,5043,5053,5055.
LOGIK 0030,2216,5065,6004,6013.
LOVE 2001.
LS ELECTRONIK 0042.
LUMA 0019,0141,0157,0169,2053,2055,2227,5064,5085,5171.
LUMATRAN 6023.
LUMATRON 0002,0019,0025,0051,0074,0088,0107,0141,0157,0169,0171,2227.
LUX MAY 0051.
LUXOR 0003,0019,0047,0077,0132,0138,0141,2004,2005,2035,2037,2047,2049,2056,2057,2058,2071,2120,2220,2226,5037,5050,5055,5078,5087,5088,5091,5095,5096,5128,5153,6003,6033.
M+P 0133.
MACTECH 2031.
MAG 6020.
MAGNADYNE 0000,0014,0123,0129,0131,0169,2000,2014,2017,2022,2025,2096,2098,2099,2104,2114,2238,5049,5053,5077,5079,5085,5086,5089,5094,5096.

TV

9

MAGNAFON 0003,0014,0043,0123,2000,2003,2004,2007,2008,2014,2024,2025,2114,2208,2238,5035,5053,5055,5077,5096.
MAGNAVOX 2017.
MAGNUM 0002,0009,0061,0067,0068,0103,0107,0111,0115,0154,0168,0169,0171,0177,0200,0291,2114.
MAJESTIC 6024.
MALONIC 6021,6023.
MANDOR 0002.
MANESTH 0002,0003,0028,0051,0169,2004,2005,2029,2091,2195,5087,5090,5094.
MANHATTAN 2020,2114,2216.
MAQMA 6005.
MARANTZ 0051,0169,1482,2023,2232.
MARECH 2029.
MARELL 0000.
MARK 0051,0169,2208.
MARKS&SPENCER 6007.
MARSHALL 2025,2031.
MASCOT 2094,5049.
MASUDA 2209.
MATCH 2004,2014,2017,2025,2064,2090,2122,2195,2213,2219,5055,5066,5086,5087,5088,5089,5094,5096,5132.
MATSUI 0003,0004,0009,0013,0019,0027,0028,0030,0051,0068,0091,0099,0101,0113,0123,0147,0164,0169,0173,0180,0248,5098,5140,6003.
MATSUKA 5055,5066.
MATSUSHITA 0065.
MAXAM 5055,5066.
MAXELL 0211,2025.
MAXIMAL 2005.
MAXMEDIA 0115.
MAXON 2025.
MAXWELL 2000,2238,5053,5077.
MCMICHAEL 0041.
MEDIATOR 0051,0169.
MEDION 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0103,0107,0115,0127,0148,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1001,1002,1005,1014,1015,1395,1397,1419,2216,5169,6003,6011,6017,6020,6023,6033.
MELECTRONIC 0003,0009,0016,0018,0021,0036,0051,0068,0109,0110,0115,0139,0169,2005,2008,2012,2014,2025,2071,2117,2127,2148,2179,2208,2215,2226,2232,5032,5037,5040,5041,5049,5050,5053,5060,5063,5077,5079,5085,5086,5089,5094,5095,5096,5155,5167.
MEMOREX 0009,0920,2108.
MEMORY 6015.
MEMPHIS 0004,0009.
MERCURY 5055,5066,5112.
METZ 0000,0038,0058,0075,0107,0135,0152,0201,0205,1398,2009,2059,2060,2061,2104,2121,2123,5031,5034,5043,5138,5168.
MGA 2031,5060,5066.
MICROMAG 6017.
MICROMAXX 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005,2216.
MICRON 2004,5055.
MICROSTAR 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005.
MIKOMI 6003.
MINERVA 0101,0135,1015,2007,2009,2035,2219,5031,5035,5063,5132.
MINISTRY OF SOUND 6003.
MINOKA 0051,2217.
MITSUBISHI 0000,0027,0030,0051,0054,0057,0060,0098,0101,0135,0205,2009,2025,2034,2041,2078,2103,2104,2122,5043,5060,5073.

TV

10

MITSURI GENERAL 2020.
MIVAR 0003,0055,0083,2000,2003,2004,2062,2063,2182,2208,2212,5036,5037,5053,5055.
MONTECH 6015.
MOTION 0043.
MT LOGIC 0090.
MTC 0132,2017,2023,2037,2115,2208,5094.
MULTI SYSTEM 0169.
MULTITECH 0003,0009,0014,0019,0027,0043,0045,0129,0131,0169,2000,2004,2017,2021,2025,2031,2034,2064,2095,2108,2110,2115,2117,2208,2216,5049,5050,5053,5055,5066,5077,5094.
MURPHY 0003,0018,0133,5035,5055,5087,5093,5094,5096,6003,6011,6018,6033.
MURPHY(UK) 2208.
MUSIKLAND 2209.
MX ONDA 6000,6004,6015.
N.E.I 2017,2031.
NAD 0141.
NAGEL 5046.
NAGOTA 5087.
NAIKO 0099.
NAONIS 0019,0108.
NARITA 5060.
NATIONAL 2167,2216,2220.
NATIONAL 0064,0101.
NEC 0027,0056,0185,1482,1483,2025,2029,2034,5054,5060,5083,5116.
NECKERMANN 0000,0003,0008,0019,0022,0051,0083,0118,0132,0169,2000,2004,2015,2023,2025,2029,2034,2037,2041,2055,2064,2094,2104,2115,2127,2128,2158,2160,2162,2227,2232,2245,5031,5043,5055,5062,5085,5087,5088,5140.
NECSTAR 5147.
NEI 0051,0068,0113,0169,5087,5094.
NEON 6007.
NEOVIA 1019.
NESCO 0129,2005,2145.
NEW WORLD 0011,2209.
NEWMAR 2004,2017,5055,5087,5094.
NEWTECH 0009,0051,2004,2215,5055.
NEXIUS 0015.
NEXT 5018,5021.
NEXT LCD 5181.
NGELEN 0021,2219.
NGERSOL 0009,2025.
NICAMAGIC 0003,2208.
NIKKAI 0002,0003,0004,0011,0051,0164,0169,2004,2091,2095,2208,2209,2227,5055,5066,5078,6003.
NIKKEI 6003.
NOBLEX 2025,2034,2079,5056,5057,5059,5060.
NOBLIKO 0003,0014,0043,0077,2003,2004,2007,2008,2021,2035,2095,2208,2238,5035,5049,5055.
NOGAMATIC 0139.
NOKIA 0021,0031,0061,0063,0077,0132,0133,0141,0142,0143,2005,2012,2014,2017,2025,2035,2037,2053,2055,2071,2108,2110,2114,2115,2120,2148,2220,2224,2226.
NORDING 2021.
NORDMENDE 0000,0021,0024,0036,0045,0051,0111,0126,0127,0139,1391,1392,1394,5042,5048,5070,5071,5096,5212,6003,6017.
NORDVISION 0169.
NORDWAY 5093.
NORFOLK 2017.
NORTON 2110.
NORWAY 2020,2115.
NOVA 2012.
NOVATRONIC 5060,5066.
NTERBUY 0009,0109,0129,2108,5050.
OCEANIC 0021,0141,0142,1011,1089,6017.
OCEANIC(ITT) 5084,5086,5087,5088,5090,5091,5095,5096.
OCTAL 2004,5055.
ODES 6020,6024.
OK. 6020,6021,6033.

TV

OKANO 0083,2025,2115.
OKI 6003.
ONCEAS 0003,2004,2025,2117,5049,5055.
ONDIOLA 2029.
ONEI 6003.
ONN 6003,6005,6007.
ONWA 0069,2031,2108,2209,5066,5067,5079,5153.
ONYX 6005,6007.
ORAVA 2017,2025.
ORAVA SLOV 5094.
ORBIT 0051.
ORBITER 2115.
ORIENT 5014.
ORION 0009,0013,0028,0030,0051,0075,0099,0123,0142,0147,0154,0159,0169,0171,0212,0248,0283,0920,2014,2015,2031,2108,2125,2213,2217,2222,5059,5066,5075,5084,5086,5087,5089,5098,5100,5108,5140,5169,6016,6017,6018,6033.
ORLINE 2209.
ORMOND 0205,2216,5053.
ORSOWE 2000,5053,5066.
OSAK 0002,0003,0004,0011,0074,2015,2108,2209,2217,5066.
OSO 0011,2209.
OSUME 0004,0029,2209.
OSUMI 6007.
OTHER LINE 5053.
OTHERS 2135,2136,2137,2185,2225,2228,2230,2239,5150.
OTIC 6000,6004,6015.
OTTO VERSAND 0001,0003,0008,0027,0051,0076,0111,0118,0121,0131,0132,0139,0141,0169,2004,2005,2009,2014,2015,2017,2022,2023,2025,2029,2034,2037,2041,2064,2082,2100,2110,2127,2232,5031,5050,5055,5087,5088,5089,5096,5167.
PACKARD BELL 0203,0204.
PAEL 0003,2003,2004,2007,2035,2208,5035,5055.
PALLADIUM 0003,0012,0083,2127,5043.
PALSONIC 2217,5055,5066.
PANAMA 0002,0003,0009,2004,2108,2208,5049,5066.
PANASONIC 0021,0064,0065,0067,0072,0101,0124,0141,0142,0152,0186,0197,2001,2003,2017,2029,2032,2055,2104,5002,5003,5025,5031,5034,5094,5096,5123,5151,6033.
PANAVISION 2108,5066.
PANAVOX 5096.
PANORAMA 2004,2108,5055.
PANORAMIC 5070.
PATHE CINEMA 0003,0037,0083,0131,2000,2001,2004,2017,2029,2208,5053,5054,5055,5082,5094.
PATHE MARCONI 0022,0037,0045,0126,0139,5212.
PAUSA 0009,2025.
PEAQ 6026,6033.
PERDIO 0004.
PERSHIN 2035,5035,5082.
PHILARMONIC 5055.
PHILCO 0000,0043,0047,0129,0131,2017,2020,2021,2022,2025,2034,2094,2100,2104,2114,2115,2157,2161,2224,5049,5054,5079,5086,5087,5089,5093,5094,5096,5103.
PHILEX 2155.
PHILHARMONIC 0003,2004,2117.
PHILIPS 0000,0003,0020,0041,0043,0051,0083,0088,0089,0111,0115,0131,0141,0154,0169,0181,0200,0202,0217,2003,2004,2010,2014,2023,2034,2036,2050,2073,2074,2104,2126,2150,2156,2168,2186,2215,2227,2232,2237,5008,5031,5043,5054,5055,5064,5071,5079,5137,5155,5167,6006,6014,6019,6025,6028,6030.
PHOCUS 0042,0095,1064,6001.
PHOENIX 0000,0051,0169,2208.
PHOENIX FORMENTI 5109,5112.
PHONOLA 0000,0051,0169,2208,5105,5106.
PILOT 5156,6005.
PILOT(1624Y) 2207.
PILOT(P1707Y) 2202.

TV

PILOT(P3033) 2205.
 PILOT(P567) 2206.
 PIONEER 0010,0021,0036,0051,0139,0145,0169,1418,1482,2000,2005,2023,2169,2215,5020,5071,5174.
 PLANTRON 0002,0051,5049,5053,5085,5087,5096.
 PLAYSONIC 2001,2004,2104,6001.
 POLAROID 6000,6003,6004,6033.
 POLESTAR 2142.
 POLYTRON 2252.
 POPPY 0009,2025.
 PORTLAND 0245.
 POWERPOINT 2219,6007.
 PRANDONI-PRINCE 0019,0123,0141,2000,2007,2030,2035,2095,2238,5035,5049,5053,5077,5085,5087,5096.
 PRAXIS 2145.
 PRECISION 0003.
 PREMIER 5015,5028,5120,5147,5162,5172,5173.
 PRIMA 0009,0021,2004,2025,2108,5055,5066.
 PRINCE 2312,2313.
 PRINCETON 6033.
 PRINTZ 0047,2014,2227.
 PRO2 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0085,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0200,0205,0206,0207,0208,0209,0210,0211,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005.
 PROFEX 0009,0043,0141,2017,2020,2021,2025,2064,2159.
 PROFILO 0171,5053,5094.
 PROFI-TRONIC 0051,2238.
 PROGRESSON 2025.
 PROLINE 0004,0051,2017,2221,5098,6003.
 PRONTECH 2017.
 PROSAT 2001.
 PROSCAN 6024.
 PROSONIC 0003,0015,0042,0068,0088,0107,0161,0169,0200,0245,2208,6005,6007,6011,6013,6017,6023.
 PROTECH 0002,0003,0009,0014,0051,0113,0129,0131,0132,0169,2025,2216,5079,5094,5098.
 PROVIEW 1001,1002,1419,6000,6004.
 PROVISION 0015,0169,0171.
 PYE 0051,0068,0169,5060.
 PYGMY 2104.
 PYMI 0009.
 QILIVE 0156,6033,7085.
 QONIX 6021.
 QUADRO 0205,6003.
 QUAL CRAFT 5035,5077.
 QUASAR 0129,2035,2238,5035,5077,5096.
 QUELLE 0002,0003,0016,0017,0018,0022,0030,0051,0129,0131,0135,0141,0169,0205,2004,2005,2006,2007,2008,2009,2010,2012,2014,2015,2017,2020,2023,2025,2034,2035,2039,2041,2048,2053,2063,2064,2071,2079,2082,2100,2102,2108,2115,2127,2128,2148,2157,2158,2159,2160,2161,2162,2216,2223,2224,2226,2227,5032,5035,5037,5040,5041,5050,5055,5057,5062,5066,5086,5089,5140.
 QUESTA 0027.
 RADIALVA 2209.
 RADIOLA 0051,0169,2168,5064.
 RADIOMARELLI 0000,0123,0129,2000,2014,2025,2104,2114,2238.
 RADIONETTE 0016,0018,2005,2012,2055,2148,5032,5041,5086,5096.
 RADIOTONE 0007,0051,2025,2108,2217.
 RANK 0017,0027.
 RANK/RBM 5035,5088,5093,5096,5107.
 RANKUK 2019.
 RBM 0017.
 RBM(UK) 2017,2019,2037,2063,2064.
 RCA 0031,2133,2139,2140,2213,2221.
 REALISTIC 2012.
 RECOR 5066.
 RECORD 2001,2114.
 REDIFFUSION 0141,5096.

TV

13

REDIFFUSION 2005,2075,2220.
 (UK)
 REFLEXION 6023.
 RELISYS 6000.
 REVOX 0051,0169,2023.
 REX 0002,0019,0021,0108,0157,2010,2018,2053,2054,2077.
 RFT 0000,0007,2005,2031,2104,2105,2238.
 RHAPSODY 2208.
 RIF 0000.
 RION HUNGARY 5065,5084,5087,5128,5129.
 RITAR 5095.
 RIZ 2017,5094.
 R-LINE 0051,0169.
 ROADSTAR 0002,0009,0011,0245,2017,2025,2031,2209.
 ROBOTRON 0000.
 ROSEN 6017.
 ROSITA 2025,2108.
 ROWA 2025,5055,5066.
 ROWIDO/KONIG 5035,5094.
 ROWSONIC 5055.
 ROYAL 5055,5066,5079.
 ROYAL LUX 2025,2031,2108,2110,2114,2146,2201,2217.
 RRADIO 0009,0011,0051,0068,0169,2007,2017,2025,2031,2035,2044,2100,2102,2108,2209,5035,5037,5050,5066,5067,5094.
 S.LORENZ 5060,5086,5095,5096.
 SABA 0000,0021,0036,0045,0111,0123,0126,0127,0139,0141,0142,0245,2000,2049,2055,2057,2065,2066,2067,2069,2076,2104,2124,2149,2151,2211,2213,2215,2220,2221,2235,2236,2244,5043,5044,5048,5053,5060,5070,5071,5073,5087,5090,5094,5096,5121,5212,6033.
 SACCS 0037.
 SAINEL 2017.
 SAISHO 0002,0003,0009,0013,0028,0030,0123,0248,2004,2014,2031,2064,2122,2170,5054,5055,5060.
 SAKAI 2004.
 SAKIO 2025,2108.
 SALORA 0019,0021,0031,0047,0061,0107,0108,0118,0121,0128,0131,0132,0138,0141,2004,2005,2037,2038,2046,2047,2048,2051,2055,2058,2064,2071,2120,2174,2175,2187,2188,2220,2226,5037,5040,5078,5085,5087,5088,5090,5092,5095,5131,5153,5164,6017,6033.
 SAMBERS 0014,0043,0123,0169,1411,2000,2001,2004,2007,2008,2021,2024,2035,2238,5035,5037,5053,5054,5077,5113.
 SAMSUNG 0002,0003,0004,0009,0030,0051,0083,0090,0104,0105,0160,0172,0312,2004,2025,2094,2108,2110,2115,2143,2191,2192,2200,2208,2242,5023,5037,5043,5055,5059,5068,5141,6022.
 SANDRA 0003,0009,2000,2004,2208.
 SANDRA COLOR 5053,5055.
 SANKYO 5058,5143.
 SANSUI 0051,0920,5017,5067,6005.
 SANYO 0003,0004,0006,0016,0018,0027,0029,0030,0031,0040,0043,0083,0127,0131,0160,2004,2012,2034,2078,2079,2080,2104,2113,2115,2122,2134,2208,5032,5055,5056,5057,5096,5102,5104,5110,5124,5143,6003.
 SAR 5055,5094.
 SAVILLE 0248.
 SBR 0041,0169.
 SCHAUB LORENZ 0015,0021,0042,0095,0141,0142,0168,0202,0205,1003,1011,1020,1385,1386,1387,1388,1389,1390,2005,2025,2031,2120,5014,6003,6033.
 SCHNEIDER 0003,0011,0051,0068,0071,0125,0131,0139,0160,0169,0177,0245,0264,2004,2005,2010,2014,2017,2020,2022,2025,2028,2030,2031,2100,2108,2179,2209,2215,2216,2227,2232,2237,2238,5030,5039,5050,5055,5064,5067,5086,5087,5088,5089,5093,5094,5096.
 SCHWAIGER 1024.
 SCOTT 2029,6015.
 SEELTECH 6021.
 SEG 0002,0003,0009,0014,0027,0043,0088,0129,0131,0168,0169,0171,0205,1014,2004,2017,2021,2025,2031,2094,2095,2105,2108,2120,2208,2216,2219,5049,5055,5077,5094.
 SEI-SINUDYNE 0000,0013,0014,0021,0075,0123,2014,

14

TV

SEITECH 2031,2104,2127,2222,2227,2238,5140.
 SELECLINE 0015.
 SELECO 0156,7085.
 SELECO 0019,0021,0027,0108,0131,0157,2005,
 2006,2010,2017,2034,2052,2053,2055,
 2068,2127,2227,5029,5030,5050,5085,
 5094,5103,5139,5152,5171.
 SENCOR 6020,6021.
 SENCORA 0009.
 SENSE 6011.
 SENTRA 0164,2005,2031,2091,2195,2209,5112.
 SET 5094.
 SHARP 0001,0005,0027,0029,0059,0187,0188,
 2034,2078,2153,5065,5112,6002,6019,
 6033.
 SHIVA 2034.
 SHIVAKI 2017.
 SHORAI 2015,5140.
 SHOY 2025,5009,5010,5066,5160,5170.
 SHOW 5145,5147.
 SIAREM 0000,0014,0123,0131,2000,2022,2104,
 2238,5053,5077,5096.
 SICATE 2001,2017.
 SICATEL 0037,5054,5094.
 SICE 2009.
 SIDEC 2017,5094.
 SIEMENS 0008,0022,0029,0135,0200,2009,2079,
 2157,2158,2159,2160,2161,2162,2224,
 5031,5035,5053,5057,5062,5123,5143.
 SIERRA 0051,0160.
 SILELIS 2017.
 SILVA 2004,2025,2034,2108,2208.
 SILVASCHNEIDE R 6021.
 SILVER 0027,2015,2031,2034,2108,5066.
 SIMTEL 5066,5167.
 SINGER 0000,0014,0129,0131,0228,2000,2004,
 2022,2025,2095,2096,2098,2104,2238,
 5049,5053,5055,5067,5077,5096,5103.
 SINUDYNE 0000,0013,0014,0015,0028,0075,0131,
 0169,2015,2022,2081,2104,2127,5075,
 5077,5086,5089,5096,5098,5108,5134,
 5140,5169,6003.
 SIREL 2000.
 SKANTIC 0021,0138.
 SKY MEDIA 6005.
 SKYMASTER 0016,0592,1166.
 SKYTRONIC 2025.
 SKYWORTH 0228,2253,2270,2273,2275,2276,2277,
 2278,2280,2281,2282,2283,2285,2286,
 2287,2288,2289,2291,2292,2293,2294,
 2295,2296,2297,2298,2299,2300,2301,
 2304,2308,2309.
 SLAVA 2004,5055.
 SLIDING 0015.
 SMARAGO 2219.
 SOGERA 2029.
 SOGO 6021,6024.
 SOLAVOX 0021,0092,2005,2220,2227,5078,5086,
 5092,5095.
 SOLONOR 2055.
 SONAWA 2209.
 SONITRON 0006,0031,2004,5055.
 SONNECLAIR 2029.
 SONOKO 0002,0003,0009,0051,0169,0245,2004,
 2025,2108,2110,5055,5066.
 SONOLOR 0006,0021.
 SONTEC 0051,0160,0169,2025,2108,2115,5050.
 SONY 0004,0009,0027,0029,0030,0076,0106,
 0127,0130,0165,0183,2034,2078,2082,
 2122,2128,2154,2249,5071.
 SOUND & VISION 0011,0014,2209.
 SOUND MASTER 2025.
 SOUNDWAVE 0051,0169.
 SOUTHERN CROSS 5050.
 SOVOS 6020.
 SOWTECH 2115,5050.
 SOYO 6005.
 SPECTRA (ASTRA) 5120,5161.
 STANDARD 0003,0009,0011,0051,0245,2004,2025,
 2029,2031,2117,2209,5049,5055,6005.

TV

15

STARLIGHT 0169.
 STARLITE 2025.
 STARLUX 2025.
 STDNEY 5053.
 STENWAY 2031,2110,2209.
 STERN 0019,0021,0157,2053,5029,5030,5070,
 5085,5171.
 STRATO 2108.
 STVI 2004,2017,5055,5094.
 STYLANDIA 2025,2031.
 SUNGOO 0206,1015,1415.
 SUNKAI 0009,2015,2209,2219,2222,5098,5140.
 SUNNY 5067,5147,5180.
 SUNSTAR 2025.
 SUNTECH 6017,6033.
 SUNWOOD 0009,0051.
 SUPERLA 0003,2000,2017,2208,5053,5094.
 SUPERSONIC 5067.
 SUPERTECH 0118,2014,2020,2025,2031,2108,2208,
 2209.
 SUPRA 0009,2025,5060,5115.
 SUPRATECH 6021.
 SUSUMU 0011,2213.
 SUTRON 0009.
 SWISSER 6005,6011.
 SYC LINE 0169,2025.
 SYDNEY 0003,2002,2208.
 SYTONG 2208.
 TACTICS 2004.
 TADISTAR 2114,5079.
 TAI WAH 2146.
 TAISHO 2017.
 TANAKI 2001.
 TANDBERG 0157,2000,2006,2015,2105,2121,2127,
 2186,2227,2235,2236,5043,5053,5070,
 5140.
 TANDY 0001,0003,0004,0011,0021,0133,2037,
 2209,5087,5088.
 TARGA 0185,1003,1004,1018.
 TASHIKO 0003,0019,0027,0041,0056,0128,2004,
 2033,2064,2208,5055,5088,5141,5143.
 TATUNG 0003,0004,0051,0123,0169,2002,2004,
 2034,2064,2083,5053,5055.
 TAURAS 6021.
 TAURUS 2017.
 TBISHI 5055,5066.
 TCL 2251,2256,2257,2258,2259,2260,2262,
 2264,2265,2266,2267,2268,2271,2272,
 2274,2279,2284,6026.
 TCM 0002,0009,0038,0042,0044,0047,0061,
 0063,0067,0068,0103,0107,0115,0127,
 0154,0168,0169,0171,0177,0185,0205,
 0206,0207,0208,0209,0210,0211,0228,
 0248,0291,0343,0924,0933,1005,1015,
 1017,1119,1413,6017.
 TD SYSTEMS 6024.
 TEAC 2004,2041,2197,2217,6000,6005,6007,
 6015,6023.
 TEAK 5055.
 TEC 0003,0009,0129,0131,0133,0248,0291,
 2004,2010,2017,2020,2025,2094,2213,
 2218,2227,5030,5049,5055,5093,5094,
 5155.
 TECCO 2004,2025,2094.
 TECHICA 2209.
 TECHLINE 2216.
 TECHNEMA 2029.
 TECHNICA 2031.
 TECHNICAL 6003.
 TECHNICS 0065,5004.
 TECHNIKA 6003,6011,6013,6015,6021,6029.
 TECHNION 6001.
 TECHNISAT 0088,0099,0154,2105,6033.
 TECHNISON 0042.
 TECHNOL 5055,5060,5066.
 TECHNOVISION 2184.
 TECHVISION 6005.
 TECHWOOD 6003,6033.
 TECNISON 2004,2025.
 TEDELEX 2025,5055,5087,5094,6005.
 TEKNANT 2025.

TV

16

TEKON 2025.
 TELE SYSTEM 6003.
 TELE+ 2173,5114.
 TELEAVIA 0022,0036,0045,0111,0126,0139,2124,2211.
 TELECINE 6033.
 TELECOR 2209.
 TELEFUNKEN 0022,0035,0036,0050,0051,0052,0078,0079,0101,0102,0108,0111,0126,0127,0139,0163,0166,0190,2017,2065,2084,2085,2086,2089,2094,2112,2157,2161,2211,2213,2215,2218,2221,2223,2224,2235,2236,2240,2241,2244,5049,5053,5059,5060,5070,5071,5072,5073,5074,5076,5094,6003,6020,6033.
 TELEGAZ 2209.
 TELEOPTA 2025.
 TELEPAC 2025.
 TELERENT 2023.
 TELESERVICE 2132,2171.
 TELESTAR 2114,5066,6011.
 TELETECH 0009,0088,0113,0129,0169,2025,2094,2216,5049.
 TELETON 0003,0118,0132,0157,2004,2010,2037,2053.
 TELEVIDEON 2208,5035,5055,5087,5096.
 TELKOM 5094.
 TELRA 5094.
 TEMPEST 5055.
 TENEL 2017,5094.
 TENSAI 0011,0018,0051,0168,2004,2012,2015,2017,2025,2029,2031,2117,2148,2209,2238,5032,5041,5049,5055,5060,5077,5080,5081,5094,5140.
 TENSON 2029.
 TER(265) 2204.
 TERRA 6032.
 TESLA 2001,2017,5054,6001.
 TESLASLOV 5094.
 TESMET 0051.
 TETRA 2029,5094.
 TEVION 0002,0009,0015,0038,0042,0044,0047,0048,0049,0061,0063,0067,0068,0103,0107,0115,0127,0154,0155,0168,0169,0170,0171,0177,0185,0200,0205,0206,0207,0208,0209,0210,0211,0214,0218,0228,0229,0248,0291,0343,0894,0924,0933,1005,1015,1016,1064,2216,6000,6003,6004.
 TEXET 0003.
 THES 6011.
 THOMSON 0003,0022,0036,0045,0050,0051,0052,0101,0102,0111,0126,0127,0139,0163,0166,0176,0185,0245,1393,2000,2001,2004,2017,2029,2035,2037,2049,2052,2053,2065,2067,2069,2076,2124,2149,2151,2211,2213,2215,2218,2219,2221,2235,2236,2244,5035,5048,5063,5069,5070,5071,5076,5087,5094,5129,5132,5149,5212,6026.
 THORN 0004,0018,0035,0037,0054,0111,0127,0141,0164,0169,5031,5032,5035,5040,5041,5053,5054,5131.
 TICSONIC 2004.
 TOBO 2025.
 TOGOSHI 2034.
 TOKAI 0004,0051,2017,5066,6021.
 TOKYO 0003,2195,2208.
 TOMASHI 2110,2209.
 TOMITA 2004,5055.
 TOP VISION 2017,5087,5094.
 TOSHIBA 0017,0027,0082,0117,0146,0164,0189,0920,1482,2004,2019,2033,2034,2041,2063,2078,2090,2091,2195,2210,2245,5055,5097,5103,6001,6003,6027,6031.
 TOWADA 0021,0131,2017.
 TOYOSI 2001.
 TR CONTINENTS 2000,5053,5085.
 TRANSONIC 5066,5079.
 TRANSTEC 2208.
 TREVI 2025,2031,2110.
 TRIAD 5054.
 TRIDENT 5005,5006,5016,5147,5162,5184.
 TRIO 6000,6004.
 TRISTAR 2031,2108,2209,5065.
 TRIUMPH 0013,0082,0123,2008,2210.

TRONIC 2004,2025.
 TTR 5029.
 TV STAR 5087.
 TVE 6020.
 UHER 0021,0043,0051,0157,2010,2011,2023,2028,2029,2030,2053,2179,2232,5029,5039,5087,5167.
 ULTRAVISION 5048,5054.
 ULTRAVOX 0000,0003,0014,0129,0133,2003,2004,2022,2029,2055,2095,2104,2208,5049,5055,5077,5085,5096,5137.
 UMC 6005,6011,6023,6029.
 UNIC 2000,2004,2017.
 UNIC RADIO 2115,5053,5055,5094.
 UNIDEN 6003.
 UNITED 0088,0169,5169,6001,6007,6011,6015,6024.
 UNITED QUICK STAR 0245.
 UNITEK 6005.
 UNIVERSUM 0002,0016,0018,0051,0061,0083,0102,0110,0122,0129,0131,0143,0169,2004,2005,2006,2008,2009,2010,2012,2014,2015,2017,2020,2023,2025,2034,2035,2041,2053,2063,2064,2071,2079,2082,2100,2108,2115,2127,2128,2148,2158,2159,2160,2161,2216,2223,2224,2226,2227,5031,5032,5033,5035,5037,5040,5041,5050,5055,5057,5062,5066,5086,5089,5090,5094,5095,5143.
 UNIVOX 0037,2001,2017,5049,5054,5086,5094.
 UNK 2017.
 URANYA 5035,5053,5060,5077.
 UTAX 2004,5055.
 VANGUARD 2004,2037,5055,5088.
 VD-TECH 6021.
 VEGAVOX 2114.
 VENTURER 6013.
 VESTEL 0019,0021,0051,0083,0092,0103,0107,0118,0129,0131,0138,0168,0169,0171,0195,0205,0215,1014,1771,2020,5049,5058,5065,5088,5093,5094,5148,6003.
 VEXA 0009,0169,2004,2031,2110,5055,5088.
 VICEROY 5055,5066.
 VICTOR 0027,0051,0065.
 VIDEO SYSTEM 0051.
 VIDEOCON 1412,2025,2090,2199.
 VIDEOLOGIC 2004,2031,5055.
 VIDEOLOGIQUE 0003,0011,2208,2209.
 VIDEOMAC 5055,5066.
 VIDEON 0248.
 VIDEOSAT 0129,2094.
 VIDEOTECHNIC 2208.
 VIDEOTON 2001,2004,2017,2020,2029,2037,2114,5050,5053,5055,5079,5084,5087,5088,5093,5094,5128.
 VISA 5035,5085,5168.
 VISAELECT 5055,5094.
 VISIOLA 0003,2208.
 VISION 0051,2029,6017.
 VISIONREX 2000.
 VISIOREX 0096,5053.
 VISTAR 0133,2255,5090,5095.
 VIVAX 0015,0042,1008,6005.
 VORTEC 0051,0169.
 VOXSON 0000,0019,0021,0043,0051,0108,2035,2104,5035,5077,5085.
 WALKER 6003,6033.
 WALKIE 2010.
 WALTHAM 0003,0037,0133,0138,2001,2004,2014,2017,2020,2114,2117,2211,5049,5087,5094.
 WATSON 0051,0169,2029,2031,2108,2209,2216,2224,5066,5085,5094,5096.
 WATT RADIO 0003,0014,0037,0131,2001,2003,2004,2014,2020,2022,2024,2115,2208,2238,5054,5055,5077,5079,5081,5086,5089,5096.
 WEGA 0000,0027.
 WEGA COLOR 2034,2078,2092.
 WEGAVOX 0015,2020,2114,5049,5079,5093,6003.
 WELLED 6001.
 WELLTECH 0042.
 WELTBlick 0051,0169,2029.

WESTON	0131,2017,5094.
WHARFEDALE	0099,6003,6015.
WHITE	0003,0014,0043,0169,2003,2004,2008,
WESTINGHOUSE	2017,2021,2029,2053,2114,2115,2208, 5029,5055,5077,5079,5094.
WINCO	2217.
WINSTON	0211,2031.
WINTERNITZ	5060,5061,5124.
WORLD OF VISION	1021.
XENIUS	6003.
XIRON	6015.
XOMAX	6007,6021.
XORO	6021.
YAKUMO	1012.
YALOS	0000.
YAMISHI	2209.
YINHE	1396.
YOKO	0002,0003,0009,0011,0051,0169,2004, 2017,2031,2064,2108,2208,2209,5055, 5066,5070,5087.
YORK	2031.
YORX	0011,2209.
YUMATU	5066,5079.
ZAMPA	2068.
ZANUSSI	0019,0108,0157,2053.
ZENITH	2132,2163.

TV/DVD (COMBOS)

AKAI	[1082&1410].
AUDIOSONIC	[1062&0090].
BEKO	1064.
BROKSONIC	0920.
CYBERCOM	[0343&0228],[0924&0210], [0933&0228].
CYBERMAXX	0894, [0343&0228],[0924&0210], [0933&0228].
CYTRON	0894, [0343&0228],[0924&0210], [0933&0228].
DUAL	[0343&0228],[0924&0210], [0933&0228].
DURABRAND	[0933&0228],[1085&1006], [1085&1007],[1086&1008], [1088&1009].
GERICOM	1064.
H&B	[0343&0228].
HB	[1089&1011].
INTERTRONIC	0894.
LIFETEC	0894, [0343&0228],[0924&0210], [0933&0228].
MEDION	0894, [0343&0228],[0924&0210], [0933&0228],1001.
MEMOREX	0920.
MICROMAXX	0894, [0343&0228],[0924&0210], [0933&0228].
MICROSTAR	0894, [0343&0228],[0924&0210], [0933&0228].
MT LOGIC	[1062&0090].
OCEANIC	[1089&1011].
ORION	0920.
PHILIPS	[0339&0181].
PHOCUS	1064.
Pr02	[0924&0210],[0933&0228], [0343&0228],0894.
PROVIEW	1001.
SANSUI	0920.
SCHAUB LORENZ	[1089&1011].
TCM	[0343&0228],[0924&0210], [0933&0228],1119.
TEVION	0894, [0343&0228],[0924&0210], [0933&0228],1064.
TOSHIBA	0920.
VESTEL	[1771&0215].

TV/DVD (COMBOS)

19

TV/VCR(COMBOS)

AIWA	0248,0291.
ALBA	0245,0248.
BAIRD	0245.
BASIC LINE	0245.
BESTAR	0245.
BLACK PANTHER LINE	0245.
BUSH	0245,0248.
COMBITECH	0248.
CONDOR	0245.
CROWN	0245.
CY TRON	0248,0291.
CYBERCOM	0248,0291.
CYBERMAXX	0248,0291.
DAEWOO	0245.
DAYTRON	0245.
DUAL	0248,0291.
ESC	0245.
GENERAL TECHNIC	0248.
GOLDSTAR	0261.
GOODMANS	0245,0283.
GRANDIN	0245.
HINARI	0248.
INNOHIT	0245.
INNOVATION	0248,0291.
ITV	0245.
KENDO	0245.
LENCO	0245.
LG	0261.
LIFE	0291.
LIFETEC	0248,0291.
LUMATRON	0245.
MAGNUM	0291.
MATSUI	0248.
MEDION	0248,0291.
MICROMAXX	0248,0291.
MICROSTAR	0248,0291.
ORION	0248,0283.
PORTLAND	0245.
Pr02	0248,0291.
PROSONIC	0245.
ROADSTAR	0245.
SABA	0245.
SAISHO	0248.
SAMSUNG	0312.
SAVILLE	0248.
SCHNEIDER	0245,0264.
SONOKO	0245.
STANDARD	0245.
TCM	0248,0291.
TEVION	0248,0291.
THOMSON	0245.
UNITED QUICK STAR	0245.
VIDEON	0248.

ASDL (BROADBAND) DTVRECEIVER

ALICE TV	1158.
DARTY	1158.
FRANCE TELECOM	1158.
FREEBOX TV	1176,1182.
MALIGNE TV	1158,1180.
MAXDOME	1239.
NEUF TELECOM	1179,1196.
NEUF TV	1179,1196.
NOOS	1143,1158,1175,1183.
NUMERICABLE	1183.

20 TV/VCR(COMBOS) ASDL

ORANGE 1158,1180,1183.
 SAGEM 1158,1177.
 SAMSUNG 1149.
 THOMSON 1175,1180.
 TPS ADSL 1158,1179,1180.
 UPC 1143,1158,1175.
 VERSATEL 1149.

SAT

*SKYMASTER 0636,1377,1378,1379,1380,1381,1382,
 CODES 1383,1384.
 @SAT 7054.
 @SKY 1138,1147.
 AB 2453.
 ABC 2381.
 ACIKO 5384,5398.
 ACOUSTIC SOLUTIONS 7053.
 ADB 7055.
 ADECQ 1340.
 AEG 7070.
 AEGIR 2435.
 AGORA 7053.
 AIRIS 7070.
 AIWA 5218.
 AKAI 0548,0552,5197,5384,5389,5430,5453,
 5468,5476.
 AKIRA 7070.
 AKIWA 5581,5582.
 ALBA 0405,0407,0508,0562,2345,2440,2536,
 7053.
 ALCOR 7083.
 ALDES 0408,2435,5239.
 ALFA GOLD 2451,2452.
 ALICETV 2427.
 ALLSAT 0410,0462,0552,2330,2360,2423,2434.
 ALLSONIC 0408,0428.
 ALPHASTAR 2423,2463.
 AMIKO 7078.
 AMNION 7054.
 AMPERE 0422.
 AMSTAR 2478.
 AMSTRAD 0415,0416,0417,0541,0555,0584,2312,
 2317,2346,2357,2402,2412,2421,2430,
 2522,5225,5347,5396,5409,5500,5534,
 5581.
 AMSTRONG 2430.
 AMTC 7070.
 ANKARO 0408,0424,0428.
 ANSONIA 7060.
 ANTIFERENCE 7053.
 ANTRON 0405,0407,2440.
 APOLLO 0405,2341.
 APP 5538.
 ARCELIK 5342,5346,5408,5424,5461,5472,5474,
 5475,5548,5571,5586.
 ARCOM 1165,1174.
 ARCON 0415,0422,0424,1144,1153,1154,1155,
 2317,2320,2402.
 ARENA 1222.
 ARION 1238.
 ARMSTRONG 2357,2423.
 ARNION 1147.
 ASAHI 5442,5484.
 ASAT 0552,2423.
 ASC 1138.
 ASDA 7053.
 ASIASEAT 5224,5256.
 ASSAHI 5419.
 ASSCOM 7050.
 AST 0435,5292.
 ASTELINK 5227.
 ASTON 0406,0594,2422,5370.

ASTRA 0429,0431,2317,2357,2412,2430,2439,
 5083,5240.
 ASTRELL 7060.
 ASTRO 0407,0428,0439,0569,2426,2435,2440,
 5239.
 ASTRX 2472,2474,2475.
 ATALANTA 5221.
 ATLANTA 5211,5240,5351,5384,5390,5589,7060,
 7070.
 ATLAXITAHDBO 5541.
 X
 AUDIOLA 7060.
 AUDIOTON 0407,0462,2330,2434,2440.
 AURA 2365,2411.
 AURORA 0602,7051.
 AUSTAR 0602,0642,0643,1224,7051.
 AVERMEDIA 5553.
 AVISION 7070.
 AVM 5573.
 AXIL 7060,7077.
 AXIS 0415,0428,0456,5083.
 BAFF 5229,5348,5392,5581.
 BAFTEC 5343.
 BARCOM 0424.
 BEKO 5278,5288,5300,5342,5346,5408,5424,
 5461,5472,5474,5548,5587.
 BELSON 7060.
 BENJAMIN 2394,5219,5255,5258,5304,5307,5310,
 5349,5350,5416,5424,5573,5581,5595.
 BEON 5245.
 BESAT 5306.
 BEST 0424,0428,2382.
 BEST BUY 7060.
 BESTECH 5498.
 BESTEL 5406.
 BESTTEL 5562.
 BQ2100
 5100PLUS
 BESTTEL 5566.
 BQ5200 PLUS
 BIGSAT 2511.
 BLACK DIAMOND 7053.
 BLACKTIGER 5601.
 BLAUPUNKT 0439.
 BOCA 2357,2421,2432,5240,7070.
 BOFTEC 5348.
 BOTECH 5189,5202,5315,5317,5446,5447,5458,
 5471,5495,5560,5565,5581,5585,5608,
 5609,5610.
 BOTECH 5536.
 HDTIMMEDELER
 BOXER 7061.
 BRAIN WAVE 0444,0549,1131.
 BRANDT 0565,0566,0567,0574,2317.
 BRIGHT 5312.
 BSKYB 0555,0584,2499.
 BT SATELLITE 0574.
 BUSH 0410,0508,0562,7053,7060,7070.
 BUSH(UK) 2341,2462,2561.
 CABLECOM 7055.
 CABOVISAO 7054.
 CALIBER 5230,5266,5299,5314,5322.
 CAMBRIDGE 2319.
 CANAL DIGITAAL 7050.
 CANAL DIGITAL 7050.
 CANAL SATELLITE 0569,0599.
 CANAL+ 0569,0599,2446,2552,7050,7068,7077.
 CANALSAT 7050.
 CANALSATELLIT 7050.
 E
 CHAPARRAL 0507,2318,2347.
 CHEROKEE 5337,5413.
 CHESS 0547,0586.
 CITIZEN 5384.
 CITYCOM 0485,0508,0640,2395.
 CLARION 5388.
 CLATRONIC 0444.

CLEMENS KAMPHUS	0491.
CNT	2435,5239.
COLUMBUS	0477.
COM HEM	7061.
COMAG	0471,1231,1233,1237,1255,5402,7070.
COMMLINK	0408.
COMSAT	2456,2512.
COMTECH	0456.
CONDOR	0428,0640,2439,5360.
CONIA	7060.
CONNEXIONS	0438,0454.
CONRAD	0640,1156,2439.
CONTEC	0456,2395.
COSAT	0462,2434.
COSHIP	0427,5409,5410.
COSMOS	5558.
COUNTRY MAN	2471.
CRONER	7070.
CROWN	2357,2430,7053.
CVS	5211,5390,5407,5457,5477,5486,5569,5590.
CYBERCOM	0412,0413,0423,0428,0442,0493,0504,0511,0514,0546,0566,0583,0586,0587,0618,0619.
CYBERLINK	2556.
CYBERMAXX	0412,0413,0423,0428,0442,0466,0478,0484,0493,0504,0511,0514,0535,0546,0566,0583,0586,0587,0618,0619,0644,0650,0652,0653,1130,1137,1138,2535,2539.
CYFRA+	2446,2473,7050,7056.
CYFROWY POLSAT	7050,7056.
CYTRON	0412,0413,0423,0428,0442,0466,0478,0484,0493,0504,0511,0514,0535,0546,0566,0583,0586,0587,0618,0619,0644,0650,0652,0653,1130,1137,1138,2535,2539.
D_SAT	5537.
DAERYUNG	0438.
DANSAT	0410.
DATCOM	2504.
DAUMLING	5264.
DAYSTAR	5418.
DAYTE	5232,5268.
D-BOX	0564,0604.
DECCA	0460.
DELTA	7061.
DENVER	7060.
DEW	0456.
DIALOGIC	7070.
DIAMOND	0461.
DICK SMITH ELECTRONICS	7070.
DIGENIUS	2535.
DIGI	7054,7061.
DIGIALITY	0640.
DIGICAG	5309.
DIGIFUSION	2537,5463.
DIGIHOME	7053.
DIGILINE	5309.
DIGILINEHDTUM MODEL CER	5540.
DIGIMASTER	5605.
DIGIO2	2546.
DIGIQUEST	0427,0485,1147,7054,7058,7070.
DIGISAT	5309.
DIGISTAR	5399.
DIGITAL	2505.
DIGITAL MSERIE	1249.
DIGITAL+	7050.
DIGITALITY	7070.
DIGITURK	5435,5451,5472,5474,5567,5587,5591.
DIGITURK (PHILIPS)	5210,5281.
DIGITURK (VESTEL)	5426.
DIGIX	5309.
DIORA	5388.

SAT

23

DIPRO	7055,7058.
DISCOVERY	5385,5391,5403.
DISISTRAT	2360.
DISKXPRESS	0424,0454.
DISTRISAT	2423.
DITRISTRAD	0462.
DIVITONE	5394.
DMT	0412,2480.
DNT	0438,0552,2360,2363,2365,2411,2423.
DOLCE	7054.
DRAGON	5204.
DRAKE	0557,2320,2375,2376,2377,2419,5469.
DREAM BOX	5478.
DREAM MULTIMEDIA	0658.
DREAMBOX	0658,2526.
DSE	7060,7070.
D-SMART	5429,5441,5444,5456.
DSR	5301,5302,5303.
DSTV	0602,7051.
DUAL	0412,0413,0423,0428,0493,0504,0511,0514,0566,0583,0586,0587,0618.
DURABRAND	2531,7053.
DVX	7060.
DYNASAT	2415,2416,5418,5419.
DYON	7070.
ECG	7070.
ECHOSTAR	0425,0464,0465,0467,0481,0578,0579,0580,0581,0586,0640,0657,0659,2321,2322,2323,2330,2348,2349,2386,2387,2390,2391,2410,2443,2456,2461,2487,2500,2506,2507,5246,5260,5327,5352,5421,5473,7050,7056.
EINHELL	0243,0405,0408,0417,2357,2421.
EISAT	2457.
ELAP	7056.
ELBE	7060.
ELECTROSAT	2491.
ELEKTA	2435,5239.
ELSA	5396.
ELTA	0405,0428,0462,0552,2330,2423,2434.
ELTON	5347.
EMANON	0405.
EMME ESSE	0428,0491,0508,2392,5352.
EMTECH	1162.
ENERGY SISTEM	7060.
ENIGMA	1248.
EP SAT	0491,0508.
EROSAT	5235.
E-TEK	1140.
ETISALAT	7061.
EUROGRAFF	5297.
EUROPA	2423.
EUROPHON	0640.
EUROSAT	2330,2357,2430,5235,5545.
EUROSKY	0428,0640,1156,2357,2421,2430,2439.
EUROSPACE	0468.
EUROSTAR	0438,2357,2439,2493.
EVA	0588,0589.
EXATOR	0405,0407,2440.
EXPER	5233.
F.M.	2330.
FAGOR	2434.
FAIRMATE	5396.
FERGUSON	0410,0472,0473,0508,0603,7053.
FIDELITY	0415,0417.
FIDELITY(UK)	2317.
FILMNET	2360.
FINEPASS	5420,5453.
FINEST	5309,5388,5480,5554.
FINLANDIA	0508.
FINLUX	0429,0480,0508,0608,2350,2351,7053.
FINNSAT	0456,0603.
FOBEM	5222,5301.
FOCUS	5319,5403.
FORCE	0535,0553,0577,2470.

SAT

24

FORTEC STAR 0470,2387,2449,2450,2480,2481,2482,
 2484,2485,2490,2496,2498,5414.
 FOXTEL 0602,1224,1225,7051.
 FOXTEL IQ 1225.
 FPE 7070.
 FRACARRO 0562,2324,2325.
 FRANCE
 SATELLITE/TV 0477.
 FRANCETELECO 2427.
 M
 FRAU HOLLE 5264.
 FREEBOXTV 2428,2559.
 FREECOM 0405,0489.
 FREESAT 7061.
 FREESAT+ 7061.
 FREEVIEW 2389,2433,2438,2441,2529,2530,2531,
 2532,2536,2537,2538,2540,2560.
 FTE 0422,2330,2334,2339.
 FUBA 0405,0424,0428,0431,0438,0439,0477,
 0480,0548,0552,2346.
 FUJI ONKYO 7068.
 FUJISAT 5342,5405.
 FUJIYAMA 5418.
 FULAN 7078.
 FULLY_16_M 5539.
 FUNNY ENVISON5553.
 FUNTACH 0587,2458.
 GALAXIS 0408,0428,0456,0462,0478,0484,0485,
 0535,0582,0583,0602,0619,2330,2434,
 5083,7050,7051.
 GALAXY 0424.
 GALAXYS 2494.
 GAMMA 5303.
 GEMA 5258.
 GI 7078.
 GIUCAR
 RECORD 2326,2352.
 GLOBECAST 1141.
 GLOBO 1156.
 GLOBSAT 7068.
 GM 5221.
 GMI 2357,2430,5221,5240.
 GOLD 5301.
 GOLD BOX 7050.
 GOLDEN MEDIA 7078.
 GOLDMASTER 5200,5206,5309,5342,5346,5347,5367,
 5388,5398,5417,5434,5568,5580,5599.
 GOLDSTAR 0489,5605.
 GOODING 0483.
 GOODMANS 0508,2531,7053.
 GOODWAY 2547,2548.
 GRACES 7056.
 GRANADA 0429.
 GRANDIN 2420.
 GRANDSON 5462,5475,5484.
 GRANVISION 1234,1235.
 GROTHUSEN 0405,0489.
 GRUNDIG 0407,0436,0439,0469,0483,0495,0508,
 0544,0550,0584,0602,2327,2340,2341,
 2551,5357,7050,7051,7053,7070,7077.
 HAIER 7060.
 HANDAN 0547,1167.
 HANSEATIC 0504,2317,2436.
 HANTOR 0405,0444.
 HANURI 2435,5239.
 HARWARD 5396.
 HAUPPAUGE 2438,5375.
 HB 0413,1162,1214,1215,1216.
 HEAD 1251,1252,1253.
 HELIOCOM 0422,2439.
 HERE 5569.
 HERZ 5396,5581.
 HEVET 2506.
 HIEMCO 5482,5501,5603.
 HIRSCHMANN 0439,0491,0522,0547,0548,0558,1156,
 1165,1174,2351,2493,5404.
 HISAWA 0444.
 HITACHI 0508,0537,2408,2462,2463,2531,7053.

SAT

25

HOMECAST 1162,1222,1223.
 HOUSTON 0462.
 HTS 2461.
 HUGHES 2462,2463.
 HUMAX 0485,0517,0582,1250,1258,1259,1260,
 2429,2510,2540,2562,5318,5369,5376,
 7061,7069.
 HUTH 0408,0411,0444,0462,0491,2357,2404,
 2430,2434,2439.
 HWA LIN 5236.
 HYUNDAI 0486,5326,5362,5388,5469,5498.
 I-CAN 7055.
 ICECRYPT 7078.
 ICX
 INTERNATIONAL 2353.
 ID DIGITAL 0485,5369.
 IMPERIAL 0562.
 INFO 2509.
 INION 7060.
 INNOVATION 0428,0493,0504,0511,0583,0586,0587,
 0618.
 INPAX 5501.
 INSAR 7053.
 INTERMIL 5259.
 INTERSAT 5271,5296,5305,5382.
 INTERTRONIC 2357,2430.
 INTERVISION 0462,2330,2434,2439,2442.
 INTSAT 7068,7077.
 IQ 7070.
 IRDETO 0602.
 ISIS 7053.
 ITALTEL 5352.
 ITT 7060.
 ITT SCHAUB
 LORENZ 5122,5381.
 ITTKIA 0429,0454,0508,0537,0548,2328,2329,
 2351,2354,5122,5381.
 JAMESON 7070.
 JEEMON 2330.
 JERROLD 2353,2383.
 JIMEX 5455,5547.
 JOHANSSON 0444,2331,2434.
 JSR 0462,2330.
 JVC 0483,2531,7053.
 KABEL
 DEUTSCHLAND 7061,7069.
 KABELBW 7069.
 KABELNOORD 7061.
 KAMASONIC 5480,5554.
 KAON 1147,5309,7054.
 KATHREIN 0439,0507,0549,0552,0607,0617,0631,
 0635,1197,1221,2332,2333,2334,2355,
 2360,2395,2423,2440.
 KAWAI 5572.
 KAYTTLI 5556,5561.
 KENDO 7053.
 KENWOOD 2446,7050.
 KING 5583.
 KODLU
 KUMANDA 5188,5189,5309.
 KONGQUE 7054.
 KONKA 5396.
 KORAX 5477,5602,5611.
 KORAX700-750 5555.
 KOSCOM 1144.
 KOSMOS 0489,0491,2334.
 KR 0407,2440.
 KREILING 0549,0631,1137,1232.
 KREISELMEYER 0439.
 KRYSTEL 7053.
 KVISION 5469.
 KYOSTAR 0405,2440.
 KYOTO 5121,5189,5221,5224,5226,5321,5325,
 5344,5361,5392,5407.
 LABGEAR 2441,7068,7077.
 LAEM_SAT 2330.
 LANDSAT 7051.
 LASAT 0428,0565,0566,0567,0630,1156,1157,
 2421,2430,2435,2439,5226,5237,5239.

SAT

26

5240.
LEADER 5402.
LEGEND 5352.
LEMON 2518.
LENC0 0405,0489,2359,2405,2406,2407.
LENG 0444.
LENNOX 0462.
LENSON 0479.
LEON 2423.
LEXUS 2423.
LG 0489.
LIFE 0583.
LIFESAT 0412,0413,0423,0428,0442,0493,0504,
0511,0514,0546,0566,0583,0586,0587,
0618,0619,2436,2519.
LIFETEC 0412,0413,0423,0428,0442,0466,0478,
0484,0493,0504,0511,0514,0535,0546,
0566,0583,0586,0587,0618,0619,0644,
0650,0652,0653,1130,1137,1138,2535,
2539.
LINE@TECH 7070.
LION 0468.
LISTO 7070.
LODOS 7053.
LOEWE OPTA 2430.
LOGIK 7053.
LOGISAT 7070.
LORENTZEN 1156,2439.
LORENZEN INC 5237,5263,5264,5265,5266,5267,5268,
5269,5270.
LORRAINE 0489.
LOWRY 7053.
LUPUS 0428.
LUXOR 0417,0429,0537,0548,2328,2335,5213.
M_&_B 2436.
MACAB 0603,2356,7050.
MACOM 2374.
MAGNAVOX 0089,2464,2465.
MAGNUM 5229,5261,5262.
MALIGNETV 2427,2432.
MANHATTAN 0421,0462,0508,0557,0633,2330,2434,
2435,5239,5261,5262,5308,7054,7068.
MARANTZ 0552,2360,2423.
MARMITEK 0641.
MARMITEK
OCTOPUS 0655,2541.
MASCOM 5239.
MASPRO 0483,0507,0508,0558,2332,2336,2341,
2414.
MATSUI 0256,0483,0574,2531,7053.
MAX 2439.
MAYSAT 5583.
MB 0504,2436.
MBOX 0442.
MEDIABOX 0569,7050.
MEDIACOM 0506,5418.
MEDIAMARKT 2357,2430.
MEDIASAT 0569,5083,7050.
MEDIASET 7058.
MEDION 0412,0413,0423,0428,0442,0466,0478,
0484,0493,0504,0511,0514,0535,0546,
0566,0583,0586,0587,0618,0619,0644,
0650,0652,0653,1130,1137,1138,1139,
1181,1217,1257,2535,2539.
MEGA 0552,2360,2423,5282,5365,5401.
MEGASAT 5581,7053,7070.
MERSAT 5569,5573,5581,5597.
METRONIC 0405,0407,0408,0424,0575,0612,0613,
0614,0615,0632,2420,2430,2435,2440,
5239,7053,7058,7060.
METZ 0439,2327.
MICO 2544.
MICRO 7070.
MICRO
ELECTRONIC 7070.
MICRO
TECHNOLOGY 0468.
MICROBOX FTA 5560.
MICROMAXX 0412,0413,0423,0428,0442,0466,0478,
0484,0493,0504,0511,0514,0535,0546,
0566,0583,0586,0587,0618,0619,0644,
0650,0652,0653,1130,1137,1138,1139,27

SAT

2535,2539.
MICROSTAR 0412,0413,0423,0428,0442,0466,0478,
0484,0493,0504,0511,0514,0535,0546,
0566,0583,0586,0587,0618,0619,0644,
0650,0652,0653,1130,1137,1138,2535,
2539,5477.
MICROTECHNOL 2512.
OGY
MINA 2418.
MINERVA 0439,0483,2327,2345.
MINISAT 5305,5363.
MINTON 5406.
MITSUBISHI 0439,0508,0574,2413.
MITSUMI 5240.
M-NET 5289.
MORETV 0423,0644,1130,1181.
MORGAN
SYDNEY 0611.
MORGANS 0552,0611,2357,2402,2421,2423,2430,
2510,5240.
MOTOROLA 2502.
MULTICHOICE 0602,7051.
MULTICHOICE(S 5254,5275.
UNMOON)
MULTISTAR 2334.
MULTITEC 0586,0587.
MURATTO 0437,0489.
NAVEX 0444.
NC+ 7056.
NEC 0509,0510,2358,2417.
NECKERMANN 2357.
NEOSAT 2477.
NEOTION 1138.
NEOTION BOX 2506.
NETA 5216,5217,5249,5251,5311,5332,5422,
5437.
NETEX 5574.
NETRON 5345.
NETRON
STARSAT 5551.
NETWORK 2337.
NEUF TELECOM 2431.
NEUF TV 2431.
NEUHAUS 0462,0479,2439,5083.
NEUSAT 2511.
NEWLINE 7060,7070.
NEWSTAR 2513,5450.
NEWWAVE 5431.
NEWYORK 5233.
NEX TIME 5199.
NEXT 5189,5191,5234,5294,5295,5297,5311,
5341,5345,5391,5401,5440,5456,5482,
5487,5496,5570,5576,5577,5578,5588,
5592,5600.
NEXT KEY 5388,5409.
NEXT MINIX 5557.
NEXT18000 5564.
HDMI.CIS
NEXT2000HD 5533.
NEXTD 5542.
NEXTPOWER 5311.
NEXTSTAR 5189,5309,5311,5360,5391,5433,5487,
5496,5553.
NEXTTVHD 5543.
NEXTWAVE 0414,0585,5201,5292,5303,5390,5392,
5433.
NIKKO 2357,2430.
NILO 7058.
NOKIA 0425,0429,0454,0508,0530,0531,0548,
0564,0604,2351,2426,2530,5439,7050.
NOMEX 0622.
NOOS 2424,2427,2508,2514,7050.
NORDMENDE 0405,0472,0508,0549,0603,5239.
NOVA 7051.
NOVA(YENICAG) 5250,5324,5330.
NOVATECH 5477.
NOVIS 0444.
NTVPLUS 7061.
NUMERICABLE 7050.
OAK 0424.

28

SAT

OCEANIC	0461,0468.
OCTAGON	0405,0407,0456.
OGGLE	2545.
OKANO	0491,2334,2357,2430.
OLIMPIA	5308.
OMEGA	5401.
ON-DIGITAL	2426,2533.
ONN	7053.
ONTIME	7061.
ONWA	5309.
OPENTEL	5403.
OPTEX	0462,0656,2330,2395,2503.
OPTICUM	2505.
OPTUS	0602,1224,7050,7051.
ORA	5309.
ORANGE	2427,2432,2514.
ORAVA	2360.
ORBIT	0435.
ORBIT SHOWTIME NETWORK	7051.
ORBITECH	0405.
ORIENT	5415,5423.
ORIGO	0468.
OSAT	0407.
OST	2317.
OTHERS	2455,2521.
OTTO VERSAND	0439,2317,2436.
OUADRAL	0408,0428,2442.
QUELLE	0417,0439,2317,2327,2439.
OUIERO	0603.
PACE	0410,0439,0508,0527,0555,0559,0584, 0617,1225,2337,2340,2341,2409,2446, 2516,5252,5254,5274,5276,5277,5281, 5328,5334,5366.
PACIFC	7050,7053.
PACIFIC	0461,2531.
PACKARD BELL	2556.
PALCOM	0431,0477,0479,7056.
PALLADIUM	0483,2357,2437.
PALSAT	2359.
PALTEC	0431.
PANASAT	2488,5273.
PANASONIC	0508,0542,0584.
PANASONIC NATIONAL	2399,2466,2528,2555.
PANDA	0410,0508,2439.
PANSAT	0490,2384.
PANTECH	0591.
PARAGON	2448.
PATRIOT	5333.
PBI	1138.
PEEKTON	7060.
PEYSS	5198,5407.
PHILIPS	0089,0434,0436,0455,0456,0483,0493, 0495,0508,0515,0543,0550,0552,0561, 0569,0574,0604,0605,0618,2341,2360, 2361,2389,2423,2440,2445,2464,2465, 2473,2524,5210,5281,7050.
PHOENIX	0456,7060.
PHONOTREND	0408,0462,0491,0652.
PILOT	5241,5272,5399.
PILOTIME	0599.
PINNACLE	0654.
PIONEER	0569,2400,2446,2529,2533,5187,5231, 7050.
PLANET	5298,5397.
POLSAT	0603,2447,2500,2508,2514.
Pr02	0412,0413,0423,0428,0442,0466,0478, 0484,0493,0504,0511,0514,0535,0546, 0566,0583,0586,0587,0618,0619,0644, 0650,0652,0653,1130,1137,1138.
Pr03	2535.
Pr04	2539.
PREDKI	0444.
PREISNER	2421,2430.
PREMIER	0569,2389,2530,2555,5195,5223,5229, 5320,5321,5387,5393,5400,5417.
PREMIERE	0442,0462,0485,0542,0564,0569,0604.

SAT

29

PREMIUMX	1134,2517.
PRIESNER	0445,2357.
PRIMACOM	7061.
PRIMESTAT	2383.
PRO BASIC	7050.
PROFI	2406.
PROFILO	5350,5411.
PROLINE	7053.
PROMAX	0508.
PROSAT	0408,0562,2344,2380,2404,2442.
PROTEK	0461,2519.
PROVISION	2435,5239.
PROZEG	5452.
QUICKLINE	7054.
RADIOLA	0552,2423.
RADIX	0438,0630,0632,1152,2363,2365,2411, 7269.
RAINBOW	0407.
RAIWAY	7061.
RC AK	2385.
Rc2	5211.
RCA	2379,2469.
RE	2330.
REBOX	2437.
REDIFFUSION	0510.
REDLINE	5577.
REDLINE	5552.
BR1000-1500- 2000	
REDLINE BR50 FULL BOX	5546.
REDPOINT	5083.
REDSTAR	0428.
REGAL	5348.
REX	5348.
RFT	0408,0552,2423.
RM(RM2200)	2486.
ROADMASTER	5245,5266,5296,5309.
ROADSTAR	7050.
ROVER	2442.
RUEFACH	2406.
SAB	1137,1144,1145,1146,1147,7054,7078.
SABA	0468,0472,0508,0543,0556,0562,0565, 0571,0572,0573,0574,0575,2435,2439, 5239.
SABRE	0508.
SAGEM	0570,0599,0603,0604,0648,2424,2427, 2447,2524,2538,2552,2557,5247.
SAIVOD	7060.
SAKURA	0456,2338,2354,5248,5322,5396.
SALORA	0429,0509,0520,0527.
SAMSUNG	0405,0426,0506,2388,2401,2402,2425, 2444,2447,2497,5211,5359,5390,7050.
SANGEAN	5228.
SANSUI	5207,5403.
SAT	0415,0435,0437.
SAT 102	2317.
SAT 103	2412.
SAT CONTROL	7054.
SAT+	0546,1137,7056.
SATCOM	0504,0523,0640,2522.
SATEC	0508.
SATECO	2330.
SATELLITE	5240.
SATLINE	2442.
SATMASTER	2402.
SATPARTNER	0405,0407,0444,0489,0491,2435,2442, 5239.
SATRBOX	5388.
SATURK	5573.
SCHACKE	2440.
SCHAUB LORENZ	1147,1162,1214,1215,1216,7060.
SCHNEIDER	0428,0455,0506,0511,0583,0586,0587, 0618,2360.
SCHWAIGER	0411,0412,0413,0427,0428,0430,0433, 0440,0504,0508,0514,0516,0565,0566, 0567,0573,0575,0576,0577,0582,0583, 0585,0587,0598,0616,0630,0631,0633,

SAT

30

0635,1131,1132,1133,1147,1152,1156,
1157,1173,1231,1233,1236,1255,2395,
2436,2534,5239,7070.

SCIENTIFIC ATLANTA 2381.

SEEMANN 0438,2357,2430,5083.

SEG 0405,0428,0444,0504,0541,0631,0634,
2436,5354,5355,5379,7053.

SELECO 0462,2434.

SEOUL 5396,5469,5482.

SERVISAT 5245,5354,5355,5379.

SET 2459,2471,5242,5253,5283,5284,5285.

SETLUX 5323.

SETLUX 2440CI 5559.

SHADOW 5396,5404.

SHARP 2527.

SHERWOOD 7056.

SHINELCO 7058.

SIEMENS 0439,1157,2327,5411,7060.

SIERRA 5569.

SIGMA 2506.

SIGMATEK 7060,7070.

SIGNAL 2385,2483.

SILVA 0489.

SILVERMAX 5573.

SIMKO 5243.

SINTRACK 2362.

SKARDIN 0546,0586,1160,2456,2457,2503,5083.

SKY 0555,0584,1151.

SKY BIRD 2330.

SKY BOX 2506.

SKY DEUTSCHLAND 7061.

SKY DIGITAL 0555,0584,2499.

SKY HD 1151.

SKY ITALIA 0555,0584.

SKY MAX 2360,2423.

SKY TELEVISION 5215.

SKY+ 0555.

SKYLAB 5215.

SKYLINK 7061.

SKYMASTER 0408,0412,0504,0506,0546,0547,0586,
0587,0588,0589,0590,0591,0592,0621,
0636,1138,1140,1159,1160,1161,1162,
1167,1244,1377,1378,1379,1380,1381,
1382,1383,1384,2391,2404,2436,2442,
2459,2461,2483,2499,2500,2503,2523,
7056.

SKYMAX 0552.

SKYPEX 1156.

SKYPLUS 1138.

SKYTECH 5574,5575,5577,5593,5594,5596.

SKYVISION 0462,2434.

SL 2421.

SM ELECTRONIC 0408,0412,0504,0506,0546,0547,0586,
0587,0588,0589,0591,0592,0621,0636,
1138,1140,1159,1160,1161,1162,1167,
1377,1378,1379,1380,1381,1382,1383,
1384,2459,2503,2547,2548.

SMART 1133,1165,1174,1234,1240,1241,1243,
1244,1246,1247,1248,1249.

SMARTHD 5542.

SME CODES 0636,1377,1378,1379,1380,1381,1382,
1383,1384.

SODEL 2563.

SOFTLINE 5409.

SONASHI 5384.

SONIX 5607.

SONY 0418,0446,0569,0584,2398,2433,2446,
2468,2554,7050.

SR 0472,2357,5240.

SSTCOM 2436,2439.

STAR 2388,2396,2492,2495.

STAR DIJITAL 5247.

STAR SAT 5412,5589.

STAR TRAK 0405.

STARBOX 0427.

STARLAND 0586.

STARMAN 7054.

STARRING 0444.

STREAM 5352,5383. **SAT**

STREAM SYSTEM 7054.

STROM 5316.

STRONG 0405,0407,0428,0454,0489,0545,0562,
0602,2339,2359,2405,2416,2435,2440,
2489,2520,5193,5239,5261,5262,5313,
5371,7050,7051,7053,7054,7055,7056,
7058,7060,7068,7070,7077,7079,7083,
7084.

STS 2336.

SUMIDA 2357,2430.

SUNNY 5266,5287,5298,5300,5309,5368,5460,
5483,5573,5579,5598,7054.

SUNSTAR 0243,0527,2357,2421,5240.

SUNTECH 7060,7070.

SUPER MAX 2479,5390,5396,5403,5423.

SUPERSON 5409.

SUPEX 2487,5222,5409.

SUPPORTPLUS 7060.

SWARTKR 0069,5544.

SYTECH 7060.

TADIRAN 2454.

TAGRA 2434.

TAKWANG 5257.

TANDBERG 0603,2360.

TANDY 0407.

TANTEC 0477,0479,0508,5426.

TAPLIN 5196,5197,5208,5384,5389,5453,5462,
5468,5476,5484,5561,9000.

TARGA 1195.

TATUNG 0460.

TBOSTON 7060.

TBS 7053.

TCM 0412,0413,0423,0428,0442,0493,0504,
0511,0514,0546,0566,0583,0586,0587,
0618,0619,2542,2543.

TEAC 7070.

TECO 2357,2430,5240.

TECHNIHALL 0416.

TECHNIKA 7053.

TECHNIKUS 2330.

TECHNILAND 2434.

TECHNISAT 0438,0479,0506,0569,0623,1219,1220,
2363,2364,2365,2366,2411,2423,2515,
7070.

TECHNOIT 7058.

TECHNOMATE 0441,1142,5364.

TECHNOSAT 2330,5203,5325,5326,5388,5401,5425,
5500.

TECHNOTREND 1131,1147,1173,1230.

TECHNOWELT 2439.

TECHSTAR 5314,5386,5550.

TECHWOOD 7053.

TEDELEX 2393.

TEKNIKA 2397.

TEKNIKSAT 5604.

TELASAT 0640,2436.

TELE SYSTEM 7056,7070.

TELE2 7061.

TELECIEL 2440.

TELECLUB 7055.

TELECOM 2330,2501.

TELEDUNYA 5535,5576,5584.

TELEFUNKEN 0405,0508,0560,0565,0566,0567,0574,
5350,5399,5411.

TELEKA 0244,0407,0438,0640,2357,2430.

TELEMASTER 2435,5239,5261,5262.

TELEMAX 2367.

TELEMEISTER 2363,2365,2395,2411.

TELESAT 0504,2436.

TELESTAR 0479,0569,1138.

TELETEK 5399.

TELEVES 0508,0610,0611,7054,7056.

TELEWIRE 0462,2330,2434,5397.

TELKOM 5302,5348,5354,5355,5379.

TELPAS 5388.

TEMPO 5222,5244,5245,5301.

TEN HAAFT 0423.

TEON 5399. **SAT**

TERMAL 5200,5211,5233,5240,5245,5246,5286,
5308,5348,5390.
 TEVEL 5377.
 TEVIN 7056.
 TEVION 0412,0413,0423,0428,0442,0466,0478,
0484,0493,0504,0511,0514,0535,0546,
0566,0583,0586,0587,0618,0619,0644,
0650,0652,0653,1130,1137,1138,1140,
2535,2539,2553.
 THOMSON 0427,0472,0492,0508,0560,0568,0569,
0570,0574,0601,0603,1156,2317,2432,
2439,2446,2508,2511,2514,2532,5212,
7050,7079.
 THORENS 0461.
 THORN 0410,0473,0508.
 THORN
FERGUSON 2317,2337,2340,2341,2409.
 THUNDERMAX 2360.
 TIOKO 2395.
 T-MOBILE 7061.
 TOCHIBO 5229,5297.
 TOFIELD 5342,5346,5348.
 TOKAI 2423,5231.
 TONBURY 0445,1159.
 TONNA 0462,0508,0546,2330,2434.
 TOP UP TV 2426,2506.
 TOPFIELD 0497,0505,0506,1203,1204,1205,5206.
 TOSHIBA 2372,2374,2467,5229,5254,7053.
 TPS 0570,2447,5247.
 TPS ADSL 2427,2431,2432.
 TPS PLATINUM 1178.
 TREKSTOR 7070.
 TRIAD 0435,0437,0489,0533.
 TRIASAT 0480.
 TRIAX 0439,0479,0565,0609,0619,7050.
 TRIDENT 5190,5409,5549.
 TRIMAX 5569.
 TRONIX 5423.
 TRWAM TV 2504.
 TVBU 5606.
 TWINNER 0610,0611,5245.
 UEC 7051.
 UEI 2564.
 UEI2 5428.
 ULTRAVOX 2330.
 UNBRANDED 2406.
 UNIDEN 0534,2342,2343,2373,2464,2465.
 UNISAT 0456,2357.
 UNITED 7058,7060.
 UNITED
SATELLITE 2370,2423,2430.
 UNITOR 0424,0444.
 UNITYMEDIA 7061,7069.
 UNIVERSUM 0439,0483,1156,2317,2350,2351,2439.
 UPC 2424,2508.
 UPC DIRECT 7061.
 US
ELECTRONICS 2353.
 USB KAYITLI 5549.
 VANTAGE 1254,5194,5209.
 VARIOSTAT 0439.
 VEA 7060.
 VECTOR 0468,2365,2411.
 VENTANA 0552,2360,2423.
 VERSATEL 2425.
 VESTEL 5205,5302,5329,5331,5348,5395,5427,
5435,5436,5445,5472,7053.
 VIA DIGITAL 0568.
 VIA SAT 0568.
 VIEWSTAR 0089.
 VISION 2525.
 VISIONNET 7078.
 VISIOSAT 0444,0462,0586,0593,0594,0595,0596,
0597.
 VISTAR 2565.
 VIVANCO 0536,0624.
 VLAANDEREN 7050.
 VOLCASAT 7060.
 VOLIA 7054. **SAT**

VOO 7050.
 VORTEC 0405,2388,2402,2444,2483,5220.
 VORTIC STAR 2444.
 V-TECH 0435,0437,0515,0537.
 WELA 2421.
 WETEKOM 2436.
 WEVASAT 0508.
 WEWA 0508.
 WHARFEDALE 7053.
 WINER 2331,2378,2476.
 WINERSAT 0444.
 WINTERNITZ 2317.
 WINX 7058.
 WISI 0435,0437,0438,0439,0508,0533,0538,
0539,0540,0597,0625,0626,0627,0628,
0629,2356,2368,2369.
 WITTENBERG 0415.
 WODEX 5452.
 WODEX10000 5561.
 WOON 5598.
 WOORISAT 2435,5239,5291,5335,5336,5338,5339,
5340,5405.
 WORLDSAT 0631.
 WOUTER 7060,7070.
 WYSI 1156.
 XCOM 5291.
 XCUISER 5326.
 XORO 7070.
 XSAT 2453,2516,5291.
 XTERME 1147,5309,5384.
 XTREME 7054.
 YENICAG 5250,5282,5324,5330.
 YES 5372.
 YONSAT 5298.
 YUMATU 5192,5211,5233,5263,5266,5390,5392,
5443,5499,5581,5597.
 YUMATU,BAFF
USB PVR 5563.
 YUNG FU 2549.
 ZAHAV 5356.
 ZEG 5399.
 ZEHNDER 0424,0428,0437,0541,0631,0632,0635,
1137,1138,1234,1235,2334,2435,5239,
7077.
 ZENITH 2371,2374,2375,2376,2377.
 ZIGGO 7061.
 ZINWELL 0485,2456.
 ZIRWATEL 5315.
 ZODIAC 0407,2440,5353,5358,5373,5378.
 ZWERGNASE 2430.

DECODER CABLE

AUSTAR 1224,0494.
 BMB 0636.
 BT 0554.
 CABLE AND
WIRELESS 0606.
 CABLECRYPT 0474.
 CABLFIME 0448,0449,0450.
 CANAL PLUS 0474.
 CLYDE
CABLEVISION 0452.
 COMCRYPT 0474.
 CRYPTOVISION 0458.
 EURODEC 0603.
 FILMNET 0474.
 FILMNET
CABLECRYPT 0474.
 FILMNET
COMCRYPT 0474.
 FOXTEL 0602,1224.
 FOXTEL IQ 1225.
 GEC 0452.
 GL 0494,0554.
 IMPULSE 0554. **DECODER CABLE**

JERROLD	0554,0494.
KABELVISION	0554.
LYONNAISE	1183.
MARMITEK	0636.
MELITA	0554.
MNET	0602,0474.
MOTOROLA	0494.
MOVIE TIME	0551.
MULTICHOICE	0474,0602.
NOKIA	0564.
NOOS	1143,1158,1175,1183.
NTL	0606,1200.
NUMERICABLE	0603.
OPTUS	1224,0494.
PACE	0606.
PHILIPS	2351.
PIONEER	0518,0521.
PVP	0554.
SAGEM	0604.
SAMSUNG	1148.
SCIENTIFIC ATLANTA	0524,0525.
SMART	1174.
STS	0551.
TELE+1	0474.
TELEPIU	0474.
TELEWEST	0606,0554.
THOMSON	1189.
UNITED	0554.
UPC	1143,1175,1184.
VIRGIN MEDIA	0606.
VISIONETICS	1185.
VISIOSAT	2351.

DVB-T

ADECO	1226.
ALBA	0451,0646.
ARCOM	1242.
BRAIN WAVE	0476.
BUSH	1261,0647,0451,0032.
CANAL+	1177.
COMAG	1229.
CYBERMAXX	0645,0650.
CYTRON	0645,0650.
DIG102	1150.
DIGENIUS	0645.
DIGIFUSION	0647.
DIGIHOME	1262.
DIGIPAL	1218.
DMT	0412.
DURABRAND	0526.
EHOSTAR	0657.
EMTECH	0476.
FREEBOX	1182.
FREEVIEW	0447,0451,0453,0457,0482,0512,0513,0519,0526,0532,0600,0646,0647,0648,0649,0651.
GBSAT	0476.
GERICOM	0443.
GOODMANS	1261,0526,0451.
GOODWAY	1163,1164.
GRUNDIG	0512,1172.
HAUPPAUGE	0482.
HB	1011,1211,1213,0476.
HITACHI	1262,0526.
HOMECAST	0476.
HUMAX	0651.
INTERSTAR	0476.
JEPSSSEN	0476.
JVC	0526.
KATHREIN	1197.
LABGEAR	0513.

DVB-T

35

LASAT	1156.
LIDCOM	0451.
LIFETEC	0645,0650.
LOGIK	1263.
MARMITEK OCTOPUS	0655.
MATSUI	0649,0526,0451.
MEDION	0645,0650.
MICO	1135.
MICROMAXX	0645,0650.
MICROSTAR	0645,0650.
NOKIA	0519,0531.
NOOS	1183.
OCEANIC	1011.
OGGLE	1136.
ON DIGITAL	0527,0531,0620.
OPTEX	0656.
PACE	0453,0527.
PACIFIC	0526.
PANASONIC	0072,0403.
PHILIPS	0600.
PIONEER	0457,0620.
Pr02	0645,0650.
PREMIERE	0600,0519.
REBOX	0476.
SAGEM	0648,1143.
SCHAUB LORENZ	1011,1211,1212,1213,0476.
SCHWAIGER	1156,1229,1173,0630.
SHARP	0059.
SKARDIN	0656.
SKYMASTER	1380,1387,1160,1383,1166,1165,1164,1163,1140,0656,0412,0636.
SMART	1247,1245,1242,1165,1133.
SMELECTRONIC	0412,0656,1165,1163,1164.
SONY	0447.
TCM	1413,1017,1119.
TECHNIKA	1262.
TECHNISAT	1218.
TECHNOTREND	1173.
TELEVES	0476.
TEVION	0645,0650.
THOMSON	0427,0532.
TOPFIELD	1204,0506.
TOP-UP TV	0527,0531,0657.
TVONICS	1263.
WHARFEDALE	1262.
WORLDSAT	0476.
YUNG FU	1166.

STB CBL

@HOME	7069.
BOXER	7061.
CABOVISAO	7054.
CAIWAY	7069,7072,7061.
CISCO	7063,7059.
COM HEM	7069,7072,7061.
DELTA	7069,7072,7061.
DIGI	7069.
DIGITALB	7054.
DNA	7069.
DU	7059.
DUNE	7082.
ER TELECOM	7054.
HD+	7061.
HUMAX	7069,7061.
KABEL DEUTSCHLAND	7069,7061.
KABELBW	7069.
KAON	7054.
KARTINATV	7082.
KISS	7059.

STB CBL

36

MEO	7059.
MOTOROLA	7059.
ONTIME	7061.
ORION TELEKOM	7082.
PACE	7059.
PORTUGAL TELECOM	7059.
PREMIERE	7069.
PRIMACOM	7061.
QUICKLINE	7054.
QWERTY	7082.
ROSTELECOM	7061.
SAGEMCOM	7069.
SAMSUNG	7072,7063.
SCIENTIFIC ATLANTA	7059.
SKY DEUTSCHLAND	7069,7061.
SONERA	7069.
STARMAN	7069,7054.
STV	7069.
TATUNG	7059.
TDC	7059.
TEASET	7069.
TELE2	7069,7061.
TELEKOM ROMANIA	7054.
UNITYMEDIA	7069.
UPC	7069.
VODAFONE	7059,7054.
VOLIA	7054.
ZIGGO	7063,7069,7059,7072,7061.

STB VAC

AC.RYAN	7066,7076.
ACER	7052.
AMIKO	7078.
ANTEC	7076,7066.
APPLE	7064.
ASROCK	7052.
ASUS	7052,7073.
BSKYB	7074.
DIGITECH	7057.
DUNE	7082.
EGREAT	7057.
ELONEX	7052.
EMINENT	7057.
EMTEC	7066,7071.
EVOLVE	7076.
FERGUSON	7076.
FUJITSU SIEMENS	7052.
GOLDEN MEDIA	7078.
HEWLETT PACKARD	7052.
HFX	7052.
ICONBIT	7076,7066.
ICYBOX	7066,7076.
INEXT	7076.
KARTINATV	7082.
MICROSOFT	7052,7081,7080.
ORION TELEKOM	7082.
PHILIPS	7065.
POBOX	7057.
POPCORN HOUR	7057.
QWERTY	7082.
RICAVISION	7052.
ROKU	7074.
SAB	7078.
SKY DEUTSCHLAND	7074.

STB VAC

37

SKY UK	7074.
SONY	7067.
SUMSION	7075.
TRUST	7052.
VIA TECHNOLOGIES	7052.
WATER	7066,7076.
WESTERN DIGITAL	7062.
XBOX	7052,7080,7081.

DVD

ACCOUSTIC SOLUTIONS	0350,0383.
AEG	0333,0894,6063.
AFREEY	0386.
AGK	6077.
AIWA	0377,0383,6064.
AKAI	0333,0350,0369,0382,0894,1082,6063.
AKASH	0346.
ALBA	0350,0351,0357,0370,0381,0384,6075, 6086.
ALL-TEL	0333.
ALLURE	6070.
AMES	0383.
AMSTRAD	0350.
AMW	1053,1054.
ANABA	0961.
ANSONIC	0356.
ANTARES	6063.
APEX	0357,0384,0390,0911,0913,0921,0949, 1083.
ARENA	0923.
ARIS	0357.
ASPIRE	0952.
A-TREND	0347.
AUDIO AUTHORITY	6066.
AUDIOSONIC	0382,1062.
AUDIOVOX	0942.
AXIL	6077.
AXION	0942.
B&K	0978.
BAIER	0349.
BAUER	6063.
BAZE	0357.
BEKO	1064.
BELSON	6070.
BEST BUY	6077.
BLACK DIAMOND	0350.
BLAUPUNKT	0384.
BLUE NOVA INTERNATIONAL	1051.
BLUE SKY	0350,0357,0373,0375.
BLUETECH	6081.
BLU-RAY	0375,1081,1107,1108,1113,1796.
BOMAN	0351,0894.
BOSE	6053.
BOSTON	6077.
BRAND UNKNOWN	6063.
BRANDT	0360,0362,0373.
BRITANIA	1795.
BROKSONIC	0920,0967.
BUSH	0350,0356,0381,0382,0384,6068,6075, 6077,6086.
CAMBRIDGE	0376.
CELESTIAL	0357.
CENTREX	0357.
CENTRIOS	0932,0951,0954,0955.
CENTRON	0932.
CENTRUM	0346,0350,0926,0927,0928.
CINETEC	0350.

DVD

38

CINEVISION 0375.
CLASSIC 0383.
CLATRONIC 0357,0894.
CMI 0923.
COBY 0332,0357,0916,0946,0947,0948,1051.
CONTEL 0894,1772.
CRITERION 0344.
CROWN 0373,0382.
C-TECH 0341.
CURTIS 0948,0950.
CYBERCOM 0330,0334,0335,0338,0339,0340,0341,0342,0343,0344,0345,0352,0356,0358,0371,0372,0373,0375,0664,0923,0924,0930,0932,0933.
CYBERHOME 0347,0912,0985,1075.
CYBERLINK 1101.
CYBERMAXX 0330,0334,0335,0338,0339,0340,0341,0342,0343,0344,0345,0352,0356,0358,0371,0372,0373,0375,0664,0893,0894,0895,0896,0897,0898,0899,0900,0901,0902,0903,0904,0905,0906,0923,0924,0930,0932,0933,0959,1066,1067,1068,1069,1070,1071,1117,1118.
CYBERVISION 1791.
CYTRON 0330,0334,0335,0338,0339,0340,0341,0342,0343,0344,0345,0352,0356,0358,0371,0372,0373,0375,0380,0664,0893,0894,0895,0896,0897,0898,0899,0900,0901,0902,0903,0904,0905,0906,0923,0924,0930,0932,0933,0959,1066,1067,1068,1069,1070,1071,1117,1118.
DAEWOO 0347,0353,0354,0355,0380,0925,0965.
DANSAI 0351.
DAYTRON 0925.
DCE 0356.
DENON 0364,0389.
DENVER 0381,0894,1051,6063.
DENZEL 0392.
DESAY 0958.
DIAMOND 0341,0373.
DIGIFRAME 0930.
DIGIHOME 0350.
DIGITOR 0382.
DIGITREX 0357.
DIGITRON 0386.
DIGIX 0962.
DIK 0356.
DISNEY 0339,0902.
DIVIDO 0380.
DIVISION 6063.
DIVX 0375,0932.
DK DIGITAL 0356.
DMTECH 0333,0351.
DRAGON SYSTEMS 0356.
DUAL 0330,0333,0334,0335,0337,0338,0340,0341,0342,0343,0344,0345,0350,0351,0352,0356,0358,0371,0372,0373,0375,0383,0392,0664,0923,0924,0933,0956,0984,6063.
DURABRAND 0333,0356,0375,0933,1085,1086,1088.
DVD 0929,1024.
D-VISION 6063.
E-BENCH 0341.
ECG 6063.
ELTA 0333,0365,0382,0894.
ELTAX 1051.
EMERSON 0339,0375,0380,1057.
ENCORE 0386.
ENZER 0392.
ESA 0956.
EUROLINE 0894.
FARENHEIT 0960.
FERGUSON 0373,6075.
FINLUX 0351,0357,0375.
FINTEC 0350.
FIRSTLINE 0373.
FISHER 0378.
FUNAI 0339.
GE 0384.
GERICOM 1064.

DVD

39

GOLDEN SPHERE 0341.
GOLDSTAR 0375,0907,0972.
GOODMANS 0333,0350,0351,0373,0382.
GO-VIDEO 0338,0351,0367,0383,0971,1059,1061.
GPX 0910.
GRADIENTE 0373,1793,1794.
GRAETZ 0392.
GRAN PRIX 0356,6063.
GRANDIN 0357.
GRUNDIG 0333,0350,0370,0373,0376,0378,0380,0385,6068.
H&B 0343,0350.
HAAZ 0341,0342.
HANSEATIC 0333,0351,0375.
HARMAN/KARDO6079.
N
HARMONKARDO 0395.
N
HB 1089,1095.
HCM 0894.
HD-DVD 0375,1081,1107,1108,1110,1796.
HE 0383.
HITACHI 0350,0367,0368,0387,0392.
HITEKER 0357.
HOHER 0356.
HOME ELECTRONICS 0383.
HOMITA 0934,0935,0936,0937,0938.
HOYO 0392.
HYUNDAI 0351.
ILO 0959.
INITIAL 0384.
INTEGRA 0374.
INTERTRONIC 0893,0894,0933.
IXONDA 0373.
JATON 0392.
JBL 0395.
JDB 0383.
JVC 0361,0362,0400,0662,0964,1058,1072,6070.
JWIN 1076,1083.
KARCHER 0351.
KAWASHI 0333.
KENDO 0350,0356,0923.
KENNEX 0350.
KENWOOD 0364,0393.
KISS 0392.
KLH 0384.
KONKA 0908,0909.
KOSS 0358,0373.
LASONIC 0341.
LAVA 6063.
LAWSON 0341,0380.
LECSON 0376.
LENCO 0350,0356,0373,1774.
LENOXX 0346,0382,0931.
LG 0375,0907,0972,1117,1797,1798,1800,6060,6071,6078,6087.
LIFE 0372,0373,0900,1117,1118.
LIFETEC 0330,0334,0335,0338,0339,0340,0341,0342,0343,0344,0345,0352,0356,0358,0371,0372,0373,0375,0664,0893,0894,0895,0896,0897,0898,0899,0900,0901,0902,0903,0904,0905,0906,0923,0924,0930,0932,0933,0959,1066,1067,1068,1069,1070,1071,1117,1118.
LIMIT 0341.
LINN 0336.
LITEON 0959,0982,1056,1059.
LODOS 0350.
LOEWE 0370,0375.
LOGIX 0351,0380.
LOOK 6075,6081.
LUMATRON 0332,0342,0350,0380,0383,1051.
LUXMAN 0367.
LUXOR 0350,0383.
MAGNAVOX 0350,0362,0370,0379,0914,0979,0980,0981.

DVD

40

MALONIC 6063.
 MANHATTAN 0350,0380.
 MARANTZ 0362,0370,0375,0379,0981,1079.
 MARK 0350.
 MASCOM 6063.
 MASTEC 0335.
 MATSUI 0350,0357,0373.
 MAXDORF 0894.
 MAXIM 0331,0350.
 MBO 0382,0383,0396.
 MEDIENCOM 0342.
 MEDION 0330,0334,0335,0338,0339,0340,0341,
 0342,0343,0344,0345,0351,0352,0356,
 0358,0371,0372,0373,0375,0664,0893,
 0894,0895,0896,0897,0898,0899,0900,
 0901,0902,0903,0904,0905,0906,0923,
 0924,0930,0932,0933,0959,1001,1066,
 1067,1068,1069,1070,1071,1115,1116,
 1117,1118,1798,1800,6060,6081.
 MEMOREX 0339,0356,0920.
 MERIDIAN 0362.
 METZ 0350,0368,0922.
 MICROMAXX 0330,0334,0335,0338,0339,0340,0341,
 0342,0343,0344,0345,0352,0356,0358,
 0371,0372,0373,0375,0664,0893,0894,
 0895,0896,0897,0898,0899,0900,0901,
 0902,0903,0904,0905,0906,0923,0924,
 0930,0932,0933,0959,1066,1067,1068,
 1069,1070,1071,1117,1118.
 MICROMEGA 0370.
 MICROSOFT 0399,1100,6057.
 MICROSTAR 0330,0334,0335,0338,0339,0340,0341,
 0342,0343,0344,0345,0352,0356,0358,
 0371,0372,0373,0375,0664,0893,0894,
 0895,0896,0897,0898,0899,0900,0901,
 0902,0903,0904,0905,0906,0923,0924,
 0930,0932,0933,0959,1066,1067,1068,
 1069,1070,1071,1117,1118.
 MINATO 0349.
 MINERVA 0380.
 MINTEK 0384.
 MIRROR 0349.
 MITSUBISHI 0350,0366.
 MONYKA 0392.
 MT LOGIC 1062.
 MUSTEK 0383.
 MYSTRAL 0356.
 NAD 0375,0394.
 NAKAMICHI 0398.
 NEC 0375,6063.
 NEOTEK 0386.
 NEUFUNK 0392.
 NEVER 6070.
 NEVR 0356.
 NEXXTECH 0932,0954,0955,0956,1772.
 NIKKEI 6063.
 NORCENT 0332,0944,0945,0948,0982.
 NORDMENDE 0356.
 NORIKO 0349.
 OCEANIC 1089.
 ODES 6070.
 OK. 6068.
 OKANO 0349,0362.
 OMNI 0382.
 ONE FOR ALL 6066.
 ONKYO 0374,0975.
 ONN 6068.
 ONX 0346.
 OPTIMIUS 0368,0922.
 ORION 0335,0920.
 ORITRON 0373.
 PACIFIC 0333,0350,0356.
 PACKARD BELL 0939,0940,1052,1101.
 PALSONIC 0357.
 PANASONIC 0364,0401,0403,0970,0974,1107,6052,
 6055,6056,6067,6082,6083,6084,6085.
 PANDA 0351.
 PHILCO 1792.
 PHILIPS 0339,0362,0370,0379,0969,0979,0980,
 0981,1080,1123,1128,1775,6054,6059,
 6061,6065,6069.
 PHOCUS 1063,1064.

DVD

41

PHONOTREND 0916.
 PIONEER 0368,0922,0968,0976,0977,1084,1108,
 6062,6073,6074.
 POLAROID 0949,0957.
 PORTLAND 0382.
 PRINZ 0356.
 PRISM 0335.
 PRO2 0330,0334,0335,0338,0339,0340,0341,
 0342,0343,0344,0345,0352,0356,0358,
 0371,0372,0373,0375,0664,0893,0894,
 0895,0896,0897,0898,0899,0900,0901,
 0902,0903,0904,0905,0906,0923,0924,
 0930,0932,0933,0959,1066,1067,1068,
 1069,1070,1071.
 PROCASTER 0905.
 PROLINE 0333,0357,0373,0376,0397.
 PROSCAN 0399.
 PROSON 0350.
 PROSONIC 0332,0341,0349,6063.
 PROVIEW 1001.
 PROVISION 0381,1051.
 Q.MEDIA 6070.
 QUADRO 0928.
 QUARTEK 1077.
 RADIONETTE 0375.
 RAITE 0392.
 RCA 0384,0399.
 RE-BL 6066.
 REDSTAR 0894,0965.
 RELISYS 0895,0923.
 REOC 0341.
 REX 0346.
 ROADSTAR 0350,0382,0383.
 RONIN 0397.
 ROTE 0361.
 ROWA 0384,0922.
 RTL 0923.
 SABA 0360,0373,0915.
 SAGA 6063.
 SAIVOD 0356.
 SALORA 0375,6063.
 SAMPO 0341,0386,0895,0923,1051.
 SAMSUNG 0338,0367,0919,0963,1050,1112,1113,
 1114,1122,6050,6051,6076.
 SANDSTROM 6063.
 SANSUI 0341,0920.
 SANYO 0333,0350,0378,1060,6063.
 SCAN 0380.
 SCHAUB 0894,1089,1095,6063.
 LORENZ
 SCHNEIDER 0333,0350,0351,0352,0356,0373,0380,
 0894.
 SCHWAIGER 0349.
 SCIENTIFIC 0341.
 LABS
 SCOTT 0357,0373.
 SEG 0341,0350,0392.
 SENCOR 6063.
 SHARP 0350,0371,0394,1055,1796.
 SHERWOOD 0391.
 SHINCO 0384.
 SHINSONIC 0384.
 SILVA 0894.
 SILVA 0356.
 SCHNEIDER
 SILVERCREST 0341,1090,1091,1092,1093.
 SINGER 0341,0382.
 SKYMASTER 0341,0382,0383.
 SM ELECTRONIC 0341,0382,0383.
 SMART 0350,0380.
 SONG 6075,6081.
 SONY 0363,0402,0986,0987,0988,0989,1081,
 6058,6064,6066.
 SOUNDMASTER 0341.
 SOUNDMAX 0341.
 SOUNDSTORM 0330.
 SOUNDWAVE 0351.
 STANDARD 0373,6070.
 STRONG 0350.

DVD

42

SUNGALE	0953.
SUNTECH	6077.
SUPERVISION	0382,0383.
SVA	0349.
SYLVANIA	0339.
SYNN	0341.
SYTECH	6077.
TANDBERG	0350.
TANGENT	1051.
TARGA	0375,0891,0907,0959,0972,1094,1115, 1117,1121.
TAURAS	6063.
TCL	6081.
TCM	0330,0333,0334,0335,0338,0339,0340, 0341,0342,0343,0344,0345,0352,0356, 0358,0371,0372,0373,0664,0900,0923, 0924,0930,0932,0933,1119.
TEAC	0333,0341,0368,0375,0384,6070,6075.
TECHNICS	0364,0399.
TECHNIKA	0356,6063,6075,6080.
TECHWOOD	0350,0370,0394.
TECO	0895,0923.
TEDELEX	0382.
TELEDEVICE	1051.
TELEFUNKEN	0333,0894,6070.
TELETECH	0350.
TENSAI	0373,0382.
TERAPIN	0943.
TESCO	6080.
TEVIN	6060.
TEVION	0330,0334,0335,0337,0338,0339,0340, 0341,0342,0343,0344,0345,0352,0356, 0358,0371,0372,0373,0375,0664,0890, 0891,0892,0893,0894,0895,0896,0897, 0898,0899,0900,0901,0902,0903,0904, 0905,0906,0917,0918,0923,0924,0930, 0932,0933,0959,0966,1064,1065,1066, 1067,1068,1069,1070,1071,1117,1118.
THETA DIGITAL	0368.
THOMSON	0359,0360,0399,1078.
TINY	1051.
TOKAI	0392,0894.
TOKIWA	0380.
TOSHIBA	0362,0920,0973,0983,1110,1111,1120, 6072.
TRANS- CONTINENTS	0356,1051.
TRANSONIC	0357.
TREDEX	0941.
TRUTECH	1075.
UMAX	0382.
UNITED	0333,0348,0357,0894,6070.
UNIVERSUM	0333,0350,0375.
VD-TECH	6070.
VENTURER	0333,6075.
VESTEL	0350,1771.
VIETA	0380.
VOXSON	0356,0382,0383.
WALKVISION	0384.
WB ELECTRONICS	6066.
WELKIN	0356.
WELLTECH	1098,1105,1106.
WESTAR	0350.
WHARFEDALE	0341,0349,0376,0386.
WILSON	0356.
WOUTER	6077.
XBOX	6057.
X-BOX	0399.
XENIUS	0358,0373.
XLOGIC	0341.
XMS	0894.
YAKUMO	0357,0905,1083.
YAMAHA	0038,0364,0370,0979,0980,1773.
YAMAKAWA	0382,0392,0397.
YUKAI	0383.
ZENITH	0375,0907.

DVD VCR(COMBOS)

APEX	0949.
BROKSONIC	0920,0967.
CINEVISION	[0375&0256].
CYBERCOM	0338,[0375&0256].
CYBERMAXX	0338,0896,0906,[0375&0256].
CYTRON	0338,0896,0906,[0375&0256].
DAEWOO	0971.
DUAL	0338,[0375&0256].
EMERSON	[0339&0231],[0375&0256].
FUNAI	[0339&0231].
GOLDSTAR	[0375&0256].
GO-VIDEO	0338,0367,0971.
HITACHI	[0387&0231].
JVC	0400.
LG	0907,[0375&0256].
LIFETEC	0338,0896,0906,[0375&0256].
MAGNAVOX	[0914&0285].
MEDION	0338,0896,0906,[0375&0256].
MICROMAXX	0338,0896,0906,[0375&0256].
MICROSTAR	0338,0896,0906,[0375&0256].
PANASONIC	0970.
PHILIPS	[0969&0285].
PIONEER	1084.
POLAROID	0949.
Pr02	[0375&0256],0338,0896,0906.
SAMSUNG	0338,0963.
SANSUI	0920.
SANYO	[0378&0258].
SILVERCREST	0256.
SONY	0402.
SYLVANIA	[0339&0231].
TARGA	[0375&0256],0907,[0375&1041].
TCM	0338,[0375&0256].
TEVION	0338,0896,0906,[0375&0256].
TOSHIBA	0362.
ZENITH	[0375&0256].

DVD-R

110	0959.
APEX	0911.
ARENA	0923.
ASPIRE	0952.
BLUE NOVA INTERNATIONAL	1051.
CENTRIOS	0951.
CMI	0923.
COBY	1051.
CYBERCOM	0923.
CYBERHOME	0912.
CYBERMAXX	0895,0905,0906,0923,0959,1071,1117.
CYTRON	0895,0905,0906,0923,0959,1071,1117.
DENVER	1051.
DUAL	0923.
ELTAX	1051.
EMERSON	1057.
GO-VIDEO	0383,1059,1061.
HB	1089.
HITACHI	0387.
JVC	1058,1072.
KENDO	0923.
LG	0907.
LIFE	1117.
LIFETEC	0895,0905,0906,0923,0959,1071,1117.
LITEON	1056,1059,0959.
LUMATRON	1051.
MAGNAVOX	0979,0980.
MEDION	0895,0905,0906,0923,0959,1071,1117.

MICROMAXX	0895,0905,0906,0923,0959,1071,1117.
MICROSTAR	0895,0905,0906,0923,0959,1071,1117.
MUSTEK	0383.
OCEANIC	1089.
PACKARD BELL	1052,0940.
PANASONIC	0403.
PHILIPS	0979,0980,1080,1128.
PHOCUS	1063.
PIONEER	0977,1084.
Pr02	0895,0905,0906,0923,0959,1071.
PROVISION	1051.
RTL	0923.
SAMPO	1051.
SAMSUNG	1112,1050.
SANYO	1060.
SCHAUB LORENZ	1089.
SHARP	1055.
SONY	0987,0988,0989.
TANGENT	1051.
TARGA	1115,0959,0891,1117,0907,1121.
TCM	0923.
TELEDEVICE	1051.
TEVION	0890,0891,0895,0905,0906,0923,0959, 1065,1071,1117.
THOMSON	0360,0359,1078.
TINY	1051.
TOSHIBA	0973,0983,0362,1111.
TRANS- CONTINENTS	1051.
YAKUMO	0905.
YAMAHA	0979,0980.
ZENITH	0907.

AUX

AUDIO TAPE PLAYERS(AUX)

AIWA	0790.
DENON	0780.
GRUNDIG	0729,0698.
HARMON KARDON	0681.
KENWOOD	0761.
MAGNAVOX	0729.
MARANTZ	0729.
NAD	0799.
ONKYO	0784.
PHILIPS	0729.
SANSUI	0729.
SHERWOOD	0783.
SONY	0754,0755,0756.
TEAC	0794.
TECHNICS	0764,0777,0786.
THOKASON	0842.
YAMAHA	0724,0772.

AUDIO AMPLIFIERS TUNERS RECEIVERS(AUX)

AIWA	7004.
ARCAM	7003,7005,7007.
ARGA	7008.
AUDIOLAB	7003,7005,7007.
AYON	7005.
BONNER	7003.
BUSH	7003,7005,7007.
CAMBRIDGE AUDIO	7003.
CENTRUM	0692.
COPLAND	7003,7005,7007.
CRITERION	0775.
CYBERCOM	0841,0775,0776.
CYBERMAXX	0841,0775,0776.

AUX

45

CYTRON	0841,0775,0776.
DENON	1048,0779,0781,7000,7021,7032,7031, 7033.
DUAL	0841,0775,0797,7000.
ELECTROCOMP ANIET	7003.
ELTA	0667,0668.
GOLDMUND	7003,7005,7007.
GRUNDIG	0697,0698,0727,7003,7005,7007.
HARMAN/ KARDON	7003,7005,7007.
HARMOVUKARD ON	0682.
JVC	7001.
KENWOOD	0761,7008.
LG	7008,7013,7014,7024.
LIFETEC	0841,0775,0776.
LINN	0857,7003,7005,7007.
LOEWE	7003,7005,7007.
MARANTZ	0727,7003,7005,7007.
MARK	7003,7005,7007.
MEDION	0841,0775,0776,7013.
MERIDIAN	7003,7005,7007.
MICROMAXX	0841,0775,0776.
MICROMEGA	7003,7005,7007.
MICROSTAR	0841,0775,0776.
MYRIAD	7003,7005,7007.
NAD	0735,0736,0737,0738,0799,0800.
NAIM	7003,7005,7007.
NUVO	0862,0863,0864,0865.
ONKYO	0785,0792,0793,0826.
PHILIPS	0734,0846,0727,7003,7005,7007,7015, 7016,7018,7025,7030.
PIONEER	7003,7005,7007.
Pr02	0841,0775,0776.
PROCEED	7003.
QUAD	7003,7005,7007.
RADIOLA	7003,7005,7007.
RADIONETTE	7008.
REVOX	7003,7005,7007.
REVOY	7003,7005,7007.
SAMSUNG	7027,7009.
SANSUI	0727.
SCHNEIDER	0791.
SHERWOOD	0782.
SILVA SCHNEIDER	7008.
SONY	0739,0740,0755,0757,0758,0759,0760, 7004.
TAG MCLAREN	7003.
TCM	0841,0775,0776,0806.
TEAC	0794,0796.
TECHNICS	0764,0777,0788.
TECHNOLOGY	7007,7003,7005.
TEVION	0775,0776,0815,0817,0841.
THEORIE & ANWENDING	0805.
THOMSON	0842,0766.
THORENS	7003,7005,7007.
UNIVERSUM	7003,7005,7007.
VICTOR	7001.
XANTECH	0867.
YAMAHA	0883,0882,0839,0838,0724,0752,0770, 0771,0772,7022,7006,7002,7011,7010, 7020,7019,7026.

MINI SYSTEMS(AUX)

AIWA	0773,0774.
CY TRON	0852,0858,0704,0745,0808,0810,0811, 0812,0820,0819.
CYBERCOM	0852,0858,0704,0745,0808,0810,0820, 0819.
CYBERMAXX	0852,0858,0704,0745,0808,0810,0811, 0812,0820,0819.
DUAL	0704,0745,0797,0820,0819,0852,0858.
E-BENCH	0811.
ELTA	0693,0745.
GRUNDIG	0707.
INSIGNIA	0731.

AUX

46

INTERTRONIC	0811.
LIFE	0879,0823,0811.
LIFETEC	0879,0823,0852,0858,0704,0745,0808, 0810,0811,0812,0820,0819.
MEDION	0879,0823,0731,0728,0852,0858,0704, 0745,0808,0810,0811,0812,0820,0819.
MICROMAXX	0852,0858,0704,0745,0808,0810,0811, 0812,0820,0819.
MICROSTAR	0852,0858,0704,0745,0808,0810,0811, 0812,0820,0819.
PIONEER	0753.
Pr02	0820,0819,0852,0858,0704,0745,0808, 0810,0811,0812.
SAMSUNG	0768.
SHARP	0768.
SILVERCREST	0828,0811,0829,0868.
SONY	0741.
TCM	0879,0880,0852,0858,0704,0745,0808, 0810,0811,0820,0819,0694,0823,0824, 0825
TEVION	0879,0823,0852,0858,0704,0745,0808, 0810,0811,0812,0820,0819,0821,0822.
WELLTECH	0881,0852,0810,0820,0819,0694,0080, 0811,0827.

ENTERTAINMENT BOX (AUXILIARY SET-TOP SOXES)

DMA	1228.
EMTEC	1096,1097.
HOME SERVER	1228.
MEDION	1228.

DIGITAL SET TOPBOXES (AUXILIARY SET-TOP SOXES)

ADECQ	1340.
ECHOSTAR	0657.
SKYMASTER	1166.
TEVION	0650,0645,0423.
YUNG FU	1166.

VIDEO ON DEMAND (AUXILIARY SET-TOP SOXES)

MAXDOME	1239.
---------	-------

WEB & COMPUTER TV (AUXILIARY SET-TOP SOXES)

BUSH	0039.
CYBERLINK	1101.
GERICOM	0443.
HAUPPAUGE	0482,1198.
NOW TV	1186.
PACKARD BELL	1101.
PANASONIC	0542.
PINNACLE	1199,1201,1202.
PREMIERE	0542.
TELEFONICA	1227.
THOMSON	0603.

MISC(AUX)

APPLE IPOD	0885.
AUDIO COMBI	0844.
CAR RADIO	0861.
CDR	0847,0675.
DBS	0845.
INTERNET RADIO	0670.
IPOD	0884.
PHILIPS	7028,7036,7038.
SAMSUNG	7023,7037,7035.
SONY	7034.
SWITCH BOX	0684.
VIDEO CD	0840.

AUX

47

YAMAHA 7017,7012,7029.

MEDIA RECEIVERS (AUXILIARY SET-TOP SOXES)

SONY NETWORK MEDIA RECEIVER	0446.
--------------------------------------	-------

MISC SET TAP BOXES (AUXILIARY SET-TOP SOXES)

PARDY LIGHT BOX	1171.
--------------------	-------

SCART SWITCH BOXES (AUXILIARY SET-TOP SOXES)

COUNTRYMAN	1168.
FUNK	1170.
MARMITEK	0641.
SKARDIN	1169.
SKYMASTER	1169.
VIVANCO	0684.

HTIB

AIWA	0377.
AMW	1054.
CENTRUM	0927.
COBY	0948.
CRITERION	[0344&0775].
CURTIS	0948.
CYBERCOM	0334,0372,[0344&0775].
CYBERMAXX	0334,0372,[0344&0775],1069,1066, 1118.
CYTRON	0334,0372,[0344&0775],1069,1066, 1118.
DUAL	0334,0372,[0344&0775].
DURABRAND	0375.
FISHER	0378.
JVC	0662,0964.
KOSS	0373.
LENC0	1774.
LENOXX	0931.
LG	0972,1797.
LIFE	1118.
LIFETEC	0334,0372,[0344&0775],1069,1066, 1118.
MEDION	0334,0372,[0344&0775],1069,1066, 1118.
MICROMAXX	0334,0372,[0344&0775],1069,1066, 1118.
MICROSTAR	0334,0372,[0344&0775],1069,1066, 1118.
NORCEWJT	0948.
ONKY0	0975.
PANASONIC	0974.
PHILIPS	[0370&0734].
PIONEER	0968,0976.
Pr02	0334,0372,[0344&0775],1069,1066.
SAMSUNG	0919,1114.
SONY	0986.
TARGA	0972,[0375&1041].
TCM	0334,[0344&0775].
TEVION	0334,0372,0892,0917,0918, [0344&0775],1069,1066,1118.
WELLTECH	1098,1105.

MEDIA CENTER PC

MCE	1100.
MICROSOFT	1100.
VISTA	1100.

AUX

48

PICTURE FRAME

AUDIOVOX	1729.
COBY	1727.
DIGITAL DÉCOR	1734.
DIGITAL LMNG	1733.
DYNEX	1729.
INSIGNIA	1731.
KODAK	1730,1720.
MEMOREX	1726.
NORCENT	1728.
PANDIGITAL	1734,1723.
PHOTOSHARE	1725.
POLAROID	1734,1732,1722.
ROYAL	1723.
SMARTPARTS	1734,1721.
TRUTECH	1724.

HOME AUTOMATION

HOME AUTOMATION	0998.
LUTRON	0887.
X-10 HOME AUTOMATION	0998.

CD

ADCOM	0848.
AIWA	0849,0850,0851,0751.
AKAI	0853,0854,0855.
ALBA	0856.
ARCAM	0732.
BESTAR	0859.
BSR	0860.
BUSH	0661.
CARRERA	0663.
CLASSIC	0807.
CONDOR	0860.
CYBERCOM	0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.
CYBERMAXX	0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819,0843,0664,0668,0674,0675,0694,0730,0742.
CYTRON	0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.
DENON	0252,0318,0665,0666.
DUAL	0843,0848,0664,0668,0675,0694,0730,0742,0743,0744,0745,0746,0747,0798,0801,0802,0803.
E-BENCH	0811.
ELTA	0878,0667,0668,0693,0694,0745.
EMERSON	0848,0859.
FISHER	0660.
GENEXXA	0859,0671,0672,0673,0675,0676,0677.
GOLDSTAR	0663.
GOODMANS	0678,0679.
GRUNDIG	0680,0697,0698,0732,0318.
HARMON KARDON	0683.
HITACHI	0685,0686,0848.
INNOVATION	0730,0742,0743,0744,0745,0746,0747.
JVC	0662,0687.
KENWOOD	0669,0688,0689,0690,0762.
LG	0663.
LIFE	0823.
LIFETEC	0823,0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.
LINN	0732.
LUXMAN	0691.
MAGNUM	0730,0742,0743,0744,0745,0746,0747.
MARANIZ	0695,0732.
MATSU	0696,0732.
MEDION	0823,0843,0728,0664,0668,0674,0675,49

CD

0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.

MEMOREX	0848,0859,0677.
MERIDIAN	0732.
MICROMAXX	0846,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.
MICROMEGA	0732.
MICROSTAR	0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0818,0819.
MISSION	0732.
MITSUBISHI	0318.
NAD	0671,0733,0735,0736,0737,0800,0318.
NAIM	0732.
NAKAMICHI	0699,0700.
NUVO	0866.
ONKYO	0840,0701,0702,0703,0785,0792.
PANASONIC	0661,0705.
PHILIPS	0847,0706,0732.
PHILIPS CD-V	0840.
PIONEER	0673,0677,0753,0318.
PRO2	0746,0747,0801,0802,0803,0807,0809,0818,0819,0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745.
PROTON	0732.
QUAD	0732.
REALISTIC	0848,0859,0675.
ROADSTAR	0706,0708.
ROTEL	0732.
SABA	0848.
SAE	0732.
SAMSUNG	0768.
SANSUI	0847,0709,0710,0711,0732.
SCHNEIDER	0860,0732.
SCOTT	0859.
SHARP	0672,0712,0713,0714.
SHERWOOD	0782.
SILVERCREST	0811.
SINGER	0803.
SKYMASTER	0778.
SONY	0671,0716,0717,0718,0741,0748,0749,0750.
TANDBERG	0732.
TCM	0880,0843,0664,0668,0674,0675,0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0823,0824,0825.
TEAC	0795.
TECHNICS	0705,0721,0763,0787.
TELEFUNKEN	0848,0318.
TEVION	0694,0730,0742,0743,0744,0745,0746,0747,0801,0802,0803,0807,0809,0813,0814,0816,0818,0819,0821,0822,0823,0843,0664,0668,0674,0675.
THEORIE & ANWENDING	0804.
THOMSON	0842,0848.
THORN	0322.
TOSHIBA	0722,0723.
UNIVERSUM	0732.
VECTOR RESEARCH	0663.
VICTOR	0687.
WELLTECH	0881,0807,0675,0694,0744,0811,0827,0828.
YAMAHA	0712,0720,0725,0771.
YORX	0708.

HDD-DVR

AMSTRAD	0555.
ARCON	1144.
ARION	1238.
BSKYB	0555.
BUSH	1261.
CANAL SATELLITE	0599.

CD HDD-DVR

CANAL+	0599.
COMAG	1231.
CONRAD	1156.
CY TRON	0905,0412,0423,0514,0644,0653,1130, 0959,1071,1117.
CYBERCOM	0412,0423,0514.
CYBERMAXX	0905,0412,0423,0514,0644,0653,1130, 0959,1071,1117.
DIGIFUSION	0647.
DIGIHOME	1262.
DMT	0412.
DREAMBOX	0658.
DUAL	0412,0423,0514.
EHOSTAR	0659.
EMTEC	1096,1097.
EUROSKY	1156.
FORCE	0553.
FORTEC STAR	0470.
FOXTEL IQ	1225.
FREEBOX	1182.
GLOB0	1156.
GOODMANS	1261.
HB	1214.
HIRSCHMANN	1156.
HITACHI	1262.
HOMECAST	1223.
HUMAX	1260,1259,1250,0651.
HYUNDAI	0486.
ILO	0959.
JVC	1072.
KATHREIN	1221,1197.
KOSCOM	1144.
LASAT	1156,1157.
LG	1800,1798,1117.
LIFE	1117.
LIFESAT	0423,0514,0412.
LIFETEC	0905,0412,0423,0514,0644,0653,1130, 0959,1071,1117.
LITEON	0959.
LOEWE	1399.
LOGIK	1263.
LORENTZEN	1156.
MARMITEK	0655.
MEDION	1800,1798,1257,0905,0412,0423,0514, 9644,0653,1130,0959,1071,1139,1115, 1181,1117.
MICROMAXX	0905,0412,0423,0514,0644,0653,1130, 0959,1071,1139,1117.
MICROSTAR	0905,0412,0423,0514,0644,0653,1130, 0959,1071,1117.
MORETV	0644,1130,1181.
NEUF TELECOM	1196.
NEUF TV	1196.
PACE	1225,0555,0453.
PACKARD BELL	1052.
PANASONIC	0403.
PHILIPS	1775,1128,0242.
PHOCUS	1063.
PINNACLE	0654.
PIONEER	0977.
Pr02	0905,0412,0423,0514,0644,0653,1130, 0959,1071.
PROCASTER	0905.
RADIX	1152.
SAGEM	0599,1143,1158.
SAMSUNG	1112.
SCHAUB LORENZ	1214.
SCHWAIGER	1231,1157,1156,1152,1132,0514,0412.
SIEMENS	1157.
SKARDIN	1160.
SKY	1151.
SKY DIGITAL	0555.
SKY+	0555.
SKYMASTER	0412,0506,1165,1159,1160,1379.
SKYPEX	1156.
SM ELECTRONIC	0412,0506,1165,1159,1160.

HDD-DVR

51

SMART	1246,1244.
SONY	0987,0988,0989.
TARGA	1115,1117,1195.
TCM	0412,0423,0514.
TECHNIKA	1262.
TECHNOTREND	1230.
TELEFONICA	1227.
TEVION	0890,0905,0412,0423,0514,0644,0653, 1130,0959,1065,1071,1117.
THOMSON	0532,0242,0326,1156,1078.
TIVO	0242.
TONBURY	1159.
TOPFIELD	1204,1203,0506.
TOSHIBA	0983,1111.
TVONICS	1263.
UNIVERSUM	1156.
WHARFEDALE	1262.
WYSI	1156.
YAKUM0	0905.

DVR/VCR

AIWA	0230,0231,0233,0248,0256,0291,0293.
AKAI	0236,0237,0238,0239,0293,0300,0307, 0329.
AKIBA	0275.
AKURA	0244,0275,0293.
ALBA	0233,0245,0246,0247,0248,0250,0275.
ALLORGAN	0311.
AMBASSADOR	0250.
AMSTRAD	0231,0253,0254.
ANITECH	0275.
ASA	0256,0257.
ASUKA	0231,0256,0257,0275.
BAIRD	0231,0237,0245,0258,0259,0293.
BASIC LINE	0233,0245,0250,0275.
BAUR	0257,0263.
BESTAR	0245,0250.
BLACK PANTHERLINE	0245.
BLAUPUNKT	0257,0260,0262,0263,0271,0309,0325.
BLUESKY	0248.
BONDSTEC	0250.
BRANDT	0303,0305.
BROKSONIC	0277,0967.
BUSH	0233,0245,0246,0247,0248,0275,0288.
CATRON	0250.
CGE	0231,0293.
CIMLINE	0233,0275.
CINEVISION	0256.
CLATRONIC	0250.
COMBITECH	0248.
CONDOR	0245,0250.
CROWN	0245,0250,0275.
CYBERCOM	0233,0248,0256,0262,0269,0291,0311, 0319,0338,0905,0906.
CYBERMAXX	0233,0248,0256,0262,0269,0291,0311, 0319,0338,0905,0906.
CYTRON	0233,0248,0256,0262,0269,0291,0311, 0319,0338,0905,0906.
DAEWOO	0245,0250,0265,0274,0319,0971.
DANSAI	0275.
DANTAX	0233.
DAYTRON	0245.
DE GRAAF	0257,0266.
DECCA	0231,0257,0293.
DUAL	0233,0248,0256,0257,0262,0291,0293, 0311,0319,0338,0905,0906.
DUMONT	0231,0257,0258,0266.
ELTA	0275.
EMERSON	0231,0256,0301,0339.
ESC	0245.
ETZUKO	0275.
FERGUSON	0259,0271,0278,0281,0293,0294,0305.

DVR/VCR

52

FIDELITY	0231,0311.
FINLANDIA	0257,0258,0266.
FINLUX	0231,0237,0257,0258,0266,0293,0298.
FIRSTLINE	0233,0256,0265,0266,0275,0298.
FISHER	0258,0279.
FLINT	0233.
FORMENTI-PHEONIX	0257.
FRONTECH	0250.
FUJITSU	0231.
FUNAI	0231,0339.
GALAXY	0231.
GBC	0250,0275.
GEC	0257.
GELOSO	0275.
GENERAL	0250.
GENERAL TECHNIC	0233,0248,0262,0311.
GOLDHAND	0275.
GOLDSTAR	0231,0256,0261.
GOODMANS	0231,0245,0250,0256,0259,0275,0282,0283.
GO-VIDEO	0338,0367,0971.
GRAETZ	0258,0293.
GRANADA	0240,0257,0258,0266,0271.
GRANDIN	0231,0245,0250,0256,0275.
GRUNDIG	0235,0243,0257,0260,0263,0271,0272,0275,0286,0287,0288,0290,0315.
HAAZ	0233.
HANSEATIC	0256,0257.
HCM	0275,0288.
HINARI	0233,0248,0275,0288,0301.
HISAWA	0233.
HITACHI	0231,0266,0293,0387,2570.
HYPSON	0233,0275.
IMPEGO	0250.
IMPERIAL	0231.
INNO HIT	0245,0250,0257,0275.
INNOVATION	0233,0248,0262,0291,0311.
INTERBUY	0256.
INTERVISION	0231.
ITT	0237,0258,0292,0293.
ITV	0245,0256.
JVC	0293,0294,0295,0400.
KAISUI	0275.
KARCHER	0257.
KENDO	0233,0236,0237,0245,0250,0265,0300.
KENWOOD	0293.
KORPEL	0275.
LENCO	0245.
LEYCO	0275.
LFE	0256,0291.
LG	0231,0256,0261,0907.
LIFETEC	0233,0248,0256,0262,0269,0291,0311,0319,0338,0905,0906.
LOEWE	0256,0257,0262,0267,0271,0325.
LOGIK	0275.
LUMATRON	0245,0274.
LUXOR	0237,0258,0281,0298.
MAGNASONIC	0258.
MAGNAVOX	0285,0914.
MAGNUM	0291.
MANESTH	0265,0275.
MARANTZ	0257,0271,0281,0299.
MATSUI	0233,0248,0256,0301.
MEDIATOR	0257.
MEDION	0233,0248,0256,0262,0269,0291,0311,0319,0338,0905,0906.
MELECTRONIC	0231.
MEMOREX	0231,0240,0256,0258,0279.
MEMPHIS	0275.
METZ	0262,0263,0267,0271,0272,0325.
MICROMAXX	0233,0248,0256,0262,0269,0291,0311,0319,0338,0905,0906.
MICROSTAR	0233,0248,0256,0262,0269,0291,0311,0319,0338,0905,0906.
MIGROS	0231. DVR/VCR

MINERVA	0263,0271.
MITSUBISHI	0231,0257,0289,0294,0298.
MULTITECH	0231,0250,0257,0275.
MURPHY	0231.
NATIONAL	0260,0262.
NEC	0293,0294,0299.
NECKERMANN	0257,0293,0301.
NEI	0257.
NESCO	0275.
NIKKAI	0250,0302.
NOKIA	0237,0240,0258,0292,0293,0300,0307.
NORDMENDE	0293,0294,0303,0305.
NTERFUNK	0257,0258.
OCEANIC	0231,0240,0293.
OKANO	0233,0300.
ORION	0233,0234,0246,0248,0283,0301,0304.
ORSON	0231.
OSAKI	0231,0256,0275.
OTTO VERSAND	0257.
PALLADIUM	0256,0271,0275,0293,0300.
PANASONIC	0260,0262,0267,0314,0321,0325,0970.
PATHE CINEMA	0301.
PATHE MARCONI	0293.
PENTAX	0266.
PERDIO	0231.
PHILCO	0299.
PHILIPS	0235,0242,0257,0271,0285,0286,0290,0293,0315,0327,0969.
PHONOLA	0257.
PIONEER	0257,0294,1084.
POLAROID	0949.
PORTLAND	0245,0250.
PRINZ	0231.
PRO2	0233,0248,0256,0262,0269,0291,0311,0319,0338,0905,0906.
PROFEX	0275.
PROLINE	0231,0288.
PROSONIC	0233,0245.
PYE	0257.
QUARTZ	0258.
QUELLE	0231,0257,0258,0263,0271,0301.
RADIOLA	0257.
REX	0293.
RFT	0250,0257.
ROADSTAR	0245,0256,0275.
RRADIO	0256,0275.
SABA	0245,0281,0293,0303,0305,0324.
SAISHO	0233,0248,0275,0301.
SALORA	0237,0258,0292,0298.
SAMSUNG	0311,0312,0338,0963.
SAMURA	0250.
SANSUI	0024,0293,0294,0920.
SANYO	0258,0279,0284.
SAVILLE	0248.
SBR	0257.
SCHAUB LORENZ	0231,0237,0258,0293.
SCHNEIDER	0231,0233,0245,0250,0256,0257,0264,0265,0275.
SEG	0275,0319.
SEL SINUDYNE	0257.
SELECO	0293.
SENTRA	0250.
SETRON	0275.
SHARP	0240,0281.
SHINTOM	0258,0275.
SHIVAKI	0256.
SIEMENS	0256,0258,0263,0271.
SILVA	0256.
SILVERCREST	0256.
SINUDYNE	0257.
SOLAVOX	0250.
SONOKO	0245.
SONOLOR	0240.

SONTEC	0256.
SONY	0232,0249,0251,0255,0308,0309,0310, 0313,0402.
STANDARD	0245.
STRONG	0244.
SUNKAI	0233.
SUNSTAR	0231.
SUNTRONIC	0231.
SUNWOOD	0275.
SYLVANIA	0231,0339.
TAISHO	0233.
TANDBERG	0263.
TARGA	0256,0907,1041.
TASHIKO	0231,0240.
TATUNG	0231,0257,0293.
TCM	0233,0248,0256,0262,0269,0291,0311, 0319,0338,0375,0905,0906.
TEC	0250.
TECHNICS	0260,0262.
TELEAVIA	0293.
TELEFUNKEN	0280,0293,0294,0295,0303,0305,0306, 0323,0324.
TENOSAL	0275.
TENSAI	0231,0256,0275.
TEVION	0233,0248,0256,0262,0269,0291,0311, 0319,0338,0905,0906.
THOMSON	0242,0245,0293,0294,0295,0305,0323, 0324,0326.
THORN	0258,0293,0301.
TIVO	0242.
TOKAI	0256,0275.
TONSAI	0275.
TOSHIBA	0257,0265,0293,0298,0319,0320,0362.
TOWADA	0275.
TOWIKA	0275.
TRIUMPH	0301.
TVA	0250.
UHER	0256.
UNITED QUICKSTAR	0245.
UNIVERSUM	0231,0235,0237,0239,0253,0256,0257, 0263,0271,0290,0315.
VICTOR	0294,0295.
VIDEON	0233,0248,0262,0311.
WELTBlick	0256.
YAMISHI	0275.
YOKAN	0275.
YOKO	0250,0256,0275.
ZENITH	0256.

Code Form

TV

TV	1-19
TV/DVD (COMBOS)	19-19
TV/VCR(COMBOS)	20-20
ASDL (BROADBAND)DTVRECEIVER	20-21

SAT

SAT	21-34
DECODER CABLE	34-35
DVB-T	35-36
STB CBL	36-37
STB VAC	37-38

DVD

DVD	38-43
DVD/VCR(COMBOS)	44-44
DVD-R	44-45

AUX

AUDIO TAPE PLAYERS(AUX)	45-45
AUDIO AMPLIFIERS TUNERS RECEIVERS(AUX)	45-46
MINI SYSTEMS(AUX)	46-47
ENTERTAINMENT BOX(AUXILIARY SET-TOP SOXES)	47-47
DIGITAL SET TOP BOXES(AUXILIARY SET-TOP SOXES)	47-47
VIDEO ON DEMAND(AUXILIARY SET-TOP SOXES)	47-47
WEB & COMPUTER TV(AUXILIARY SET-TOP SOXES)	47-47
MISC(AUX)	47-48
MEDIA RECEIVERS(AUXILIARY SET-TOP SOXES)	48-48
MISC SET TAP BOXES(AUXILIARY SET-TOP SOXES)	48-48
SCART SWITCH BOXES(AUXILIARY SET-TOP SOXES)	48-48
HTIB	48-48
MEDIA CENTER PC	48-48
PICTURE FRAME	49-49
HOME AUTO MATION	49-49

CD

CD	49-50
----	-------

HD

HDD-DVR	50-52
---------	-------

DVR

DVR/VCR	52-55
---------	-------