




### 3.1 If you need 5° tilt, use tilt hook 04



### 3.2




M6 M8




## Installation Instruction

LED/LCD/PLASMA  
FULL-MOTION WALL MOUNT




### 4 Hang TV on wall mount

### 4.1



### 3 Attach bracket to TV

### Adjusting TV




### IMPORTANT SAFETY INSTRUCTOPNS




Please read through these instructions completely to be sure you're comfortable with this easy install process. Also check your TV owner's manual to see if there are any special requirements for mounting your TV. If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact your Customer Service.

**CAUTION:** Avoid potential personal injuries and property damage!





- This product is designed for use in solid concrete, stud wall, and concrete block walls. DO NOT install into drywall alone!!
- The wall must be capable of supporting three times the weight of the TV and mount combined.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- This wall mount is intended for use with television that does not exceed the maximum weight capacity designated. Using this mount with products heavier than the maximum weight indicated may result in instability causing possible injury.







# 1 preparation



## Tools required



## 2 Attach mount to wall (Solid Concrete wall)



## Attach mount to wall (Wood Stud wall)