



3.1




M6 M8



4


Hang TV on wall mount

4.1



3

Attach bracket to TV




IMPORTANT SAFETY INSTRUCTOPNS


Please read through these instructions completely to be sure you're comfortable with this easy install process. Also check your TV owner's manual to see if there are any special requirements for mounting your TV. If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact your Customer Service.

CAUTION: Avoid potential personal injuries and property damage!


- This product is designed for use in solid concrete, and concrete block walls - DO NOT install into drywall alone!!
- The wall must be capable of supporting five times the weight of the TV and mount combined.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- This wall mount is intended for use with television that does not exceed the maximum weight capacity designated. Using this mount with products heavier than the maximum weight indicated may result in instability causing possible injury.

Adjusting TV







Parts for assembly



01 Wall plate x1




02 Bracket x2




Hardware



A M8x60 Lag Bolts x6




B Plastic wall Anchor x6



C M6x20mm x4



D M8x16mm x4



E Spacer x4



F 8mm washer x10











G 6mm washer x4



H M5x30mm x2

1 preparation



2

Attach mount to wall
(Solid Concrete wall)

Attach mount to wall
(Wood Stud wall)